



Assembly Technologies

Alpha Controller User Manual v3.1



Important Safeguards

For your protection, please read these instructions completely, and keep this manual for future reference. Carefully observe and comply with all warnings, cautions and instructions placed on the equipment or described in this manual.

Contents

Getting Started	1
1.1 Warnings and Cautions	1
1.2 User Manual Conventions	2
1.3 Specifications, Layout and Display	2
1.4 Installation Instructions	4
1.4.1 Plinth	5
1.4.2 Controller	6
1.4.3 Alpha Controller E-Stop Precaution	6
Programming.....	7
2.1 QA Alpha Controller Navigation and Programming.....	7
2.2 Display.....	7
2.2.1 Scroll Bar	7
2.2.2 Dropdown.....	8
2.2.3 Menu Tree.....	8
2.2.4 Tabs.....	8
2.2.5 Character Scrollbar	8
2.2.6 Run Display.....	8
2.3 Faults.....	9
2.4 Log.....	9
2.5 Alpha Controller Programming.....	10
2.5.1 Setup Menu: 1. Jobs	11
2.5.1.1 Wizard Screens	11
2.5.1.2 Setup: Job Tab	15
2.5.1.3 Setup: Task Button	16
2.5.1.4 Setup: Step Button (Step 1 – Step 12).....	19
2.5.1.4.1 Strategy TC/AM.....	19
2.5.1.4.2 Strategy AC/TM.....	23
2.5.1.4.3 Strategy AC/TC	27
2.5.1.4.4 Strategy BACK (Backoff).....	32
2.5.1.4.5 Strategy RATE	40
2.5.1.4.6 Strategy YIELD.....	44
2.5.1.4.7 Strategy AC/TA	36
2.5.1.5 Setup: Manage	40
2.5.1.6 Setup: Exit	52
2.5.2 Setup Menu: 2. Communications	52
2.5.3 Setup Menu: 3. Other.....	56
2.5.4 Setup Menu: 4. Full Backup/Restore.....	71
2.5.5 Service	72
2.5.5.1 Tool.....	72
2.5.5.2 Controller	73
2.5.6 Analyze	74
QPM DC Electric Tools	77
3.1 Tool Specifications.....	77
3.2 Operator Protection	77
Repetitive Motion	78

Alpha Controller

3.2.1	Hearing Protection	78
3.2.2	Vibration.....	79
3.2.3	Breathing Protection.....	79
3.3	Tool Installation.....	79
3.3.1	Sockets and Adapters	79
3.3.2	Suspension Devices.....	80
3.3.3	Cable Installation	80
3.4	QPM Tools.....	80
3.4.1	Display and Multiple Function Button for Hand Held Tools 80	
3.4.2	MFP Mode	81
3.4.3	Tool Memory	81
3.4.4	Tightening Cycle Counters.....	81
3.5	Tool Operation.....	82
3.5.1	Directional Control.....	82
3.5.2	Torque Reaction Devices.....	82
3.5.3	Tool Temperature.....	83
3.5.4	Tool Status Lights	83
3.5.5	Setting Torque, Angle, and Other Operating Parameters	83
3.6	Special Application Tools.....	83
3.6.1	Exposed Gear Socket Tools	83
3.6.2	Tubenut Nutrunners	84
	Controller Connections and Inputs/Outputs	85
4.1	Alpha Controller Connections	85
4.1.1	Alpha Controller Power Cord	85
4.1.2	Alpha Controller Tool Connector.....	85
4.1.3	Alpha Controller Serial Connector.....	86
4.1.4	Alpha Controller Ethernet Connector	87
4.1.5	Alpha Controller (Model QA1001 _D_) DeviceNet™.....	87
4.1.6	Alpha Controller (Model QA1001 _P_) Profibus Port	87
4.1.7	Alpha Controller (Model QA1001 __V) Input and Output Connector	88
4.2	Assignable Input/Output Functions	88
4.2.1	Input Descriptions	90
4.2.2	Output Descriptions.....	96
	Software Map.....	99
5.1	Setup	99
5.1.1	Wizard.....	99
5.1.2	Job	99
5.1.2.1	Task.....	99
5.1.2.2	Step	100
5.1.3	Communications	104
5.1.4	Other	104
5.1.5	Full Backup/Restore.....	106
5.2	Service.....	106
5.2.1	Tool.....	106
5.2.2	Controller	107
5.3	Analyze.....	107

Appendix A – Embedded Toolbox.....	109
Glossary	111
Warranty.....	115






Getting Started

This manual is intended to promote proper and safe use and give guidance to owners, employers, supervisors, and others responsible for training and safe use by operators and maintainers. Please contact your Stanley Sales Engineer for further information or assistance on Stanley training or assembly tool operations.

1.1 Warnings and Cautions

Definitions

The safety notices and warnings for protection against loss of life (the users or service personnel) or for the protection against damage to property are highlighted in this document by the terms and pictograms defined here. The terms used in this document and marked on the equipment itself have the following significance:

- Warning** - Indicates that death or severe personal injury **may** result if proper precautions are not taken.
- Caution** - Indicates that property damage may result if proper precautions are not taken.
-  - Indicates an electrical hazard. This icon appears as a part of a Danger, Warning, or Caution notice.
-  - Indicates a general hazard. This icon appears as a part of a Danger, Warning, or Caution notice.
-  - Indicates that eye protection should be worn. This icon appears as a part of a Danger, Warning, or Caution notice.
-  - Read and understand all the safety recommendations and all operating instructions before operating tools and controllers.
-  - Indicates an item of special interest.



W A R N I N G

To Avoid Injury:

- Read and understand all the safety recommendations and all operating instructions before operating tools and controllers. Save these instructions for future reference.
- Train all operators in the safe and proper use of power tools. Operators should report any unsafe condition to their supervisor.
- Follow all safety recommendations in the manual that apply to the tools being used and the nature of the work being performed.
- Verify that all warning labels illustrated in this manual are readable. Replacement labels are available at no additional cost from **STANLEY ASSEMBLY TECHNOLOGIES**.

Qualified Personnel



WARNING

To Avoid Injury:

- Only allow suitably qualified personnel to install, program, or maintain this equipment and or system.
- These persons must be knowledgeable of any potential sources of danger and maintenance measures as set out in the Installation, Operations, and Maintenance manual.
- This product must be transported, stored, and installed as intended, and maintained and operated with care to ensure that the product functions correctly and safely.
- Persons responsible for system planning and design must be familiar with the safety concepts of automation equipment.


1.2 User Manual Conventions

Underlined text indicates glossary terms. Menu options appear in ***Arial 10 bold italic***.

1.3 Specifications, Layout and Display

Dimensions	Width:	6.0 in	152 mm		
	Height:	14.2 in	361 mm		
	Depth:	10.3 in	262 mm		
Weight:		17 lb	7.7kg		
Operating Conditions:	Temperature:	32 to 122 °F (0 to +50 °C)			
	Humidity:	0 to 95 % non-condensing			
Power Source:	100 – 120 VAC, 50/60 Hz, 15 service or 220 – 240 VAC, 50/60 Hz, 15 service				
Power Consumption:	Stand by:	0.2 A (amperes)			
	Continuous:	1-2.5 kVA			
Tool Motor Power:	Service Rating:	E02/E_23	E_33/E_34	E44/E45	E55
Consumption	@ 115 VAC:	15A	15A	20A	-
	@ 230 VAC:	10A	10A	10A	16A
	Continuous kVA:	0.3	0.7	1	1.7

Alpha Controller



Item	Functional Description
1	Red, Green, Yellow LEDs for Limits Evaluation
2	Display
3	Function Keys with Active Label Above
4	Cursor Keys with Center Button to Expand Lists
5	Maintenance Due and ATC Active LEDs
6	Numeric Keypad to Enter Numbers or Select Options
7	Controller Label and Serial Number
8	Power Switch
9	Power Input
10	USB Port for Data Transfer
11	Optional 24 VDC Input/Output Connector
12	Tool Connector
13	Serial Connectors
14	Optional Device-Net Connector
15	Optional Profibus Connector
16	Ethernet Connector

1.4 Installation Instructions



WARNING

To Avoid Injury:

- Always wear eye and foot protection when installing equipment.
- Only use equipment and accessories specifically designed to operate with Stanley assembly tools and use them only in the manner for which they are intended.
- Do not install worn, damaged, or modified equipment that may be unsuitable for safe use.
- Train all operators in the safe and proper use of power tools. Operators should report any unsafe condition.
- Store idle tools and accessories in a safe location accessible only by trained persons.
- Disconnect power source (air, electricity, etc.) from tool prior to making adjustments, changing accessories, or storing.
- Prior to operation, always check and test tools and accessories for damage, misalignment, binding or any other condition that may affect operation. Maintenance and repair should be performed by qualified personnel.
- Do not operate tools in or near explosive environments or in the presence of flammable liquids, gases, dust, rain or other wet conditions.
- Keep the work area clean, well lit and uncluttered.
- Keep unauthorized personnel out of the work area.
- Install modules in dry, indoor, non-flammable, and non-explosive environments only.
- Qualified personnel should perform installation and programming. Follow all manufacturer installation instructions, applicable regulatory electrical codes, and safety codes.
- Limit module access to trained and qualified personnel. Lock module cabinets.

DC Electric Tools & Controllers:

- Install tools in dry, indoor, non-flammable, and non-explosive environments only – Humidity: 0 to 95% non-condensing and Temperature: 32 to 122 °F (0 to +50 °C).
- Installation, maintenance and programming should be performed by qualified personnel. Follow all manufacturer installation instructions and applicable regulatory electrical codes and safety codes.
- Tool and controller plugs must match the outlet. This equipment must be earth grounded. Never modify a plug in any way or use any adaptor plugs.
- Avoid body contact with electrically energized surfaces when holding a grounded tool.
- Prior to connecting a power source, always ensure the tool or controller is turned off.
- Limit controller access to trained and qualified personnel. Lock controller cabinets.



WARNING


ELECTRICAL HAZARD

To Avoid Injury:

- Do not use this product near water, for example near a washbowl, wet basement, or the like.
- This product should be located away from heat sources such as radiators or other devices that produce heat.
- This product should not be subjected to vibration or shock or in close contact with water or other liquids.
- To minimize electrical interference, place the module as far away from possible sources of electrical noise, such as arc welding equipment.

Alpha Controller

1.4.1 Plinth



Plinths are used as wall mount brackets for Alpha Controllers. This allows for easy installation, quick change out and provides for neat cable management.


Plinths and Alphas can be mounted individually for single tool operation or grouped for multiple applications.

Plinths connect to each other with four 10-32 machine screws through openings on the top and right side to threaded openings on the bottom and left side. When plinths are mounted next to each other, the center to center distance between the mounting holes in different plinths is 2" (50.8 mm). When plinths are mounted one above another, the center to center distance between the mounting holes in different plinths is 6" (152.4 mm).

1. Install the Alpha Controller either directly to the wall or to a plinth.
2. Fasteners through four mounting holes secure plinths to a wall or other surface. Plinths can be connected using 10-32 threaded holes on the bottom and left side and through holes on the top and right side.

1.4.2 Controller

1. Make sure the bolts of the barrel-latches [5] on the plinth are retracted. Place the lower flange of the Alpha controller [1] into the lip [2] on the plinth.
2. Align the slot [3] in the flange with the lower mounting-pin [4] on the plinth while placing. Rotate the top of the controller back towards the plinth.
3. Place the openings on the upper flange of the controller [6] over the upper mounting pins [7] on the plinth. Release the bolts on the barrel-latches [5] making sure the bolts enter the two barrels [8] on the controller.
4. Connect the Alpha Controller to a power source.
5. Connect the tool cable to the Alpha controller and press the power switch on the controller.



1.4.3 Alpha Controller E-Stop Precaution



WARNING


INTEGRATED E-STOP CIRCUIT NOT PRESENT

To Avoid Injury:

When an Alpha controller connects to a tool where a fault can result in personal injury or substantial damage to property, an E-stop circuit is required. An E-stop circuit must be created in the external power supply line.

Programming

2.1 QA Alpha Controller Navigation and Programming



The Alpha controller's three navigation and input areas facilitate menu navigation, selection and data input:

- Menu buttons
- Arrows and Toggle button
- Keypad


Labels for the four interactive menu buttons [1] change with menu selection. If the label is blank, the button has no function for the current display.

The up/down arrows [2] navigate menu and character selections; the left/right arrows enable backspace and space, as well as navigate between tabs. The toggle button [3] switches between modes and selects/accepts choices (synonymous with **OK** menu button).

The numeric keypad [4] facilitates data input, menu selection (where applicable) and job/task selection when enabled.

2.2 Display

2.2.1 Scroll Bar



A scroll bar appears when more items are available than space within the display to allow them to be visible. The up arrow [1] and down arrow [3] direct scrolling. The black/white scroll bar [2] indicates which list items are currently displayed. No scroll bar means all items are currently displayed.


To navigate between menu items, use the up/down arrows or use the keypad to identify the corresponding menu item number.

2.2.2 Dropdown



A dropdown [1] arrow appears to the right of menu items with multiple choices. To view these choices, first select the menu item using the up/down arrows or, use the keypad to identify the corresponding menu item number. Then, use the toggle button to expand the dropdown. The up/down arrows scroll through the choices and the toggle button selects/accepts the highlighted choice.

2.2.3 Menu Tree




A menu tree [1] appears beside related menu items.

2.2.4 Tabs




Tabs [1] appear at the top when multiple menu selections exist. To navigate between tabs, use the left/right arrows. The active tab is white; inactive tabs are grey.

2.2.5 Character Scrollbar



This scrollbar enables adding: a-z, A-Z, 0-9, space, _, -, &, *, \$, #, @, !, and a period (language and/or field determines character availability). The up arrow [1] and down arrow [3] direct scrolling with the active character [2] displayed between. Use the Alpha Controller's up/down arrows to scroll through character choices. The left arrow backspaces. The right arrow moves one position to the right to input next character. Push toggle button or OK menu button to accept entry.

2.2.6 Run Display



Icons [1] identify controller events (see list below). Displays last torque reading and units [2] when a tool is connected. Specifies target bolt count [3] of active job. The run screen displays unless other programming functions [4] are in use. Shows active job [5] and active task [6].

Tool Shutoff Codes indicate why a tightening cycle shutoffs prior to completion.

Tool Shutoff Code	Description
TIME	Tightening time exceeds programmed cycle abort time value
STOP	Spindle stopped by either the operator or other device before completing cycle
125%	Spindle stopped due to torque achieving greater than 125% torque limit for the spindle
FAULT	Faults are described in section 2.3
STALL	Spindle is in a stall status

Alpha Controller Icons

Icon	Status	Description
	Locked	Password required to make changes
	Unlocked	Changes possible, automatically re-locks in time
	Busy/working	Please wait for controller to finish working
	Warning system not operable	Check the run screen
	Force on or off	Identifies an input/output forced on or off

Alpha Controller

⊗ Stop Tool Operation

No strategy selected
Bolt count has been met, needs reset
An Input is disabling the tool
Reset Reject has is enabled and active

2.3 Faults



The display background color in normal operation is white. In the event of a fault, the display background becomes red and the fault description appears on the screen.

Over current Fault!
Logic Voltage Fault!
Position Feedback Fault!
Transducer Span Fault!
Temperature Fault!
Unrecognized Tool!
Tool Communications!
Transducer Current Fault!
Transducer Zero Fault!
Internal Fault!
Unsupported Tool!

2.4 Log



From the main menu (run display), press the down arrow to view the log of controller events.

The log lists events by occurrence date and time using the internal clock as set by the user. Events included in the log are rundowns and faults.

The data stored for each rundown includes:

Torque – the torque value achieved from Audit step, or last step performed, if the Threshold Torque has been exceeded.

Angle – the angle value achieved from Audit step, or last step performed, if the Snug Torque has been exceeded.

Date – controller date when rundown was performed

Time – controller time when rundown was performed

Job – the job number in which the rundown was performed

Task – the task in which the rundown was performed

Status – the overall status of the rundown

SOC – shutoff code other than normal, see section 2.2.6 for a list of Shutoff Codes

Bolt – which bolt # being fastened, used only during error proofing operations

Step – the step achieved at shutoff, not necessarily the final step in the task

Part ID – the number stored in the Part ID buffer, could be from a barcode scan or received over the serial port, Fieldbus, Ethernet or keypad.

The data stored for each fault includes:

Event – the name of the fault, see section 2.3 for a list of faults

Date – controller date when fault was asserted / cleared

Time – controller time when fault was asserted / cleared

Source – the source of the fault, the list of sources is below:

Tool

Servo (DSP)

Controller (PC-104)

Embedded Toolbox (PC)

State – asserted or cleared

Use the down arrow to access the data. Once viewing the Log Screen, use the up/down arrows to scroll. To view the event's detail screen, highlight an event and press the toggle button. Use the up/down arrows to scroll through the data if there is more than will fit on the screen.

Data cannot be exported from the log screen. This action is performed using the EXPORT button found via the STATS button under Analyze; see section 2.5.6.

2.5 Alpha Controller Programming



WARNING

EXCESSIVE TORQUE CONDITION

To Avoid Injury:

- Only trained and qualified personnel should program controllers.
- Never set control limits above the maximum rating of the tool.
- Setting control limits above the maximum rating of the tool can cause high reaction torque.
- Always test for proper tool operation after programming the controller.

The controller uses three main menus to display information and enable programming:

- **Setup** menu
- **Service** menu
- **Analyze** menu

Icon Legend	Icon Description	Navigation
	Menu Buttons	Press to activate menu option noted above button.
	Left/Right Arrow Keys	Navigate tabs as well as backspace and space.
	Up/Down Arrow Keys	Scroll through menu selection and character selection.
	Toggle Button	Selects option for data input, accepts changes.
	Numeric Keypad	Used for data input, menu selection, job/task selection and for entering PART ID.

The left column shows the currently defined Alpha Controller settings and menu choices. The Options Screen column shows options for each selection. Screen navigation options appear above each screen.












Default Screens	Options Screen

Alpha Controller

2.5.1 Setup Menu: 1. Jobs

The **Setup** menu programs the controller to operate a spindle or tool. Settings are saved per Job with optional Task and Step assignments. Most controllers will operate with a single Job, Task and Step. Tasks control tool operation for tightening a fastener which can have one or more steps. Steps are defined by available strategies such as TC/AM (Torque Control, Angle Monitoring). The Wizard can be used to setup a Task for simple rundowns. Creating a name for Jobs, Tasks and Steps is optional but helpful when multiples Jobs and Tasks exist.

2.5.1.1 Wizard Screens

Wizard Screens	Options Screen
<p>The Wizard assists with programming the controller to assign a <u>Task</u> which operates a single spindle. To function, the Wizard requires a tool to be connected. This example shows Torque & Angle Strategy. Selecting another Strategy affects subsequent screen options. The wizard automatically appears when there are no configured jobs. To access the wizard when jobs exist, choose Setup, 1. Jobs, Manage, 1. Add, then choose before or after selected tab.</p>	
 <p>WIZARD Strategy TORQUE & ANGLE Units NM Thread Direction CW NEXT CANCEL</p>	 <p>WIZARD Strategy TORQUE <TC/AM> Units ANGLE <AC/TM> Thread Direction CW OK CANCEL</p>
 <p>WIZARD Strategy TORQUE & ANGLE Units NM Thread Direction CW NEXT CANCEL</p>	 <p>WIZARD Strategy TORQUE & ANGLE Units FTLB Thread Direction INLB INOZ OK CANCEL</p>
 <p>WIZARD Strategy TORQUE & ANGLE Units NM Thread Direction CW NEXT CANCEL</p>	 <p>WIZARD Strategy TORQUE & ANGLE Units KGCM Thread Direction NCM NDM OK CANCEL</p>
 <p>WIZARD Strategy TORQUE & ANGLE Units NM Thread Direction CW NEXT CANCEL</p>	 <p>WIZARD Strategy TORQUE & ANGLE Units NM Thread Direction CCW OK CANCEL</p>
 <p>WIZARD High Torque 35 Low Torque 0 Snug Torque 0 PREV NEXT CANCEL</p>	
 <p>WIZARD Low Torque 0 Snug Torque 0 High Angle 9999.9 PREV NEXT CANCEL</p>	
 <p>WIZARD Snug Torque 0 High Angle 9999.9 Low Angle 0 PREV NEXT CANCEL</p>	

Wizard Screens

Options Screen

WIZARD

High Angle	9999.9
Low Angle	0
Speed	1115

PREV NEXT CANCEL

WIZARD

High Angle	9999.9
Low Angle	0
Speed	1115

PREV NEXT CANCEL

WIZARD

High Angle	9999.9
Low Angle	0
Speed	1115

PREV NEXT CANCEL



WIZARD

<input type="checkbox"/> Wobble
<input checked="" type="checkbox"/> Slow Seek
<input type="checkbox"/> Start Delay

PREV NEXT CANCEL

WIZARD

<input checked="" type="checkbox"/> Slow Seek
<input type="checkbox"/> Start Delay
<input type="checkbox"/> Condition Fastener

PREV NEXT CANCEL



WIZARD

<input checked="" type="checkbox"/> Wobble
<input type="checkbox"/> Slow Seek
<input type="checkbox"/> Start Delay

PREV NEXT CANCEL

WIZARD-WOBBLE

Angle Target	360
Speed	60
Max Torque	1.75

PREV NEXT CANCEL

WIZARD-WOBBLE

Angle Target	360
Speed	60
Max Torque	1.75

PREV NEXT CANCEL

WIZARD-WOBBLE

Angle Target	360
Speed	60
Max Torque	1.75

PREV NEXT CANCEL

WIZARD

<input checked="" type="checkbox"/> Start Delay
<input type="checkbox"/> Condition Fastener
<input type="checkbox"/> Pre-Torque

PREV NEXT CANCEL

WIZARD-START DELAY



Delay Time	0.25
Max Torque	35

PREV NEXT CANCEL

WIZARD-START DELAY

Delay Time	0.25
Max Torque	35

PREV NEXT CANCEL



Wizard Screens

Options Screen

WIZARD-BACKOUT	
Angle Target	1800
Torque Target	0
Speed	115
<div>PREV NEXT CANCEL</div>	

WIZARD	
<input type="checkbox"/> ATC	
<input type="checkbox"/> Backout Fastener	
<input checked="" type="checkbox"/> Fastener Release	
<div>PREV NEXT CANCEL</div>	

WIZARD-RELEASE	
Speed	55
Angle Target	30
Max Torque	17.5
<div>PREV NEXT CANCEL</div>	

WIZARD-RELEASE	
Speed	55
Angle Target	30
Max Torque	17.5
<div>PREV NEXT CANCEL</div>	

WIZARD-RELEASE	
Speed	55
Angle Target	30
Max Torque	17.5
<div>PREV NEXT CANCEL</div>	



WIZARD-SLOW SEEK	
Angle Target	180
Speed	60
Max Torque	3.5
<div>PREV NEXT CANCEL</div>	

WIZARD-SLOW SEEK	
Angle Target	180
Speed	60
Max Torque	3.5
<div>PREV NEXT CANCEL</div>	












WIZARD-SLOW SEEK	
Angle Target	180
Speed	60
Max Torque	3.5
<div>PREV NEXT CANCEL</div>	





WIZARD	
Complete!	
<div>PREV FINISH CANCEL</div>	

Alpha Controller

2.5.1.2 Setup: Job Tab









Job Tab Screens	Options Screens
Tool settings apply to all Tasks.	
	
	
	
	
	
	

Job Tab Screens	Options Screens
	








2.5.1.3 Setup: Task Button















Task Tab Screens	Options Screens
------------------	-----------------

A maximum of 99 tasks can be created.

Alpha Controller

Task Tab Screens	Options Screens
 <div> <div>TASK 1</div> <div>Threshold Torque</div> <div>Statistical Threshold</div> <div>Disassembly Speed</div> <div>9999</div> <div>EXITMANAGESTEP▼BACK</div> </div>	
 <div> <div>TASK 1</div> <div>Statistical Threshold</div> <div>Disassembly Speed</div> <div>Disassembly Acceleration</div> <div>3000</div> <div>EXITMANAGESTEP▼BACK</div> </div>	
 <div> <div>TASK 1</div> <div>Disassembly Speed</div> <div>Disassembly Acceleration</div> <div>Cycle Lock-Out</div> <div>0</div> <div>EXITMANAGESTEP▼BACK</div> </div>	
 <div> <div>TASK 1</div> <div>Disassembly Acceleration</div> <div>Cycle Lock-Out</div> <div>Torque Audit Step</div> <div>LAST▼</div> <div>EXITMANAGESTEP▼BACK</div> </div>	
 <div> <div>TASK 1</div> <div>Cycle Lock-Out</div> <div>Torque Audit Step</div> <div>Angle Audit Step</div> <div>LAST▼</div> <div>EXITMANAGESTEP▼BACK</div> </div>	
 <div> <div>TASK 1</div> <div>Torque Audit Step</div> <div>Angle Audit Step</div> <div>Torque Rate</div> <div>LAST▼</div> <div>EXITMANAGESTEP▼BACK</div> </div>	 <div> <div>TASK 1</div> <div>Torque Audit Step</div> <div>Angle Audit Step</div> <div>Torque Rate</div> <div>LAST▼</div> <div>OKCANCEL</div> </div>

Task Tab Screens	Options Screens
	  
 	    
 	
 	








Alpha Controller

2.5.1.4 Setup: Step Button (Step 1 – Step 12)

Step Screens (Step 1 – Step 12)

Options Screens

Step settings affect only the active Task. Each strategy selection has different configuration options.



Step Screens (Step 1 – Step 12)	Options Screens
	
	
	
	

2.5.1.4.1 Strategy TC/AM

Strategy TC/AM Screens









Options Screens


















Step settings affect only the active Task.

Strategy TC/AM Screens	Options Screens
	






Strategy TC/AM Screens	Options Screens
 	
 	
 	
 	
 	

Alpha Controller



Strategy TC/AM Screens	Options Screens
  <div data-bbox="349 357 836 493"> <p>STEP 1</p> <p>Low Angle <input type="text" value="0"/></p> <p>Angle Bailout <input type="text" value="9999.9"/></p> <p>Downshift Mode <input type="text" value="DISABLED"/></p> <p>EXIT MANAGE BACK</p> </div>	
  <div data-bbox="349 651 836 787"> <p>STEP 1</p> <p>Angle Bailout <input type="text" value="9999.9"/></p> <p>Downshift Mode <input type="text" value="DISABLED"/></p> <p>Soft Stop <input type="text" value="YES"/></p> <p>EXIT MANAGE BACK</p> </div>	
 <div data-bbox="349 945 836 1081"> <p>STEP 1</p> <p>Downshift Mode <input type="text" value="DISABLED"/></p> <p>Soft Stop <input type="text" value="YES"/></p> <p>Current Off Time <input type="text" value="0.001"/></p> <p>EXIT MANAGE BACK</p> </div>	   <div data-bbox="868 945 1356 1081"> <p>STEP 1</p> <p>Downshift Mode <input type="text" value="DISABLED"/></p> <p>Soft Stop <input type="text" value="MANUAL"/></p> <p>Current Off Time <input type="text" value="0.001"/></p> <p>OK CANCEL</p> </div>
	<div data-bbox="868 1123 1356 1260"> <p>STEP 1</p> <p>Downshift Mode <input type="text" value="MANUAL"/></p> <p>Downshift Torque <input type="text" value="0"/></p> <p>Downshift Speed <input type="text" value="0"/></p> <p>EXIT MANAGE BACK</p> </div> <div data-bbox="909 1270 1364 1407"> <p>STEP 1</p> <p>Downshift Mode <input type="text" value="MANUAL"/></p> <p>Downshift Torque <input type="text" value="0"/></p> <p>Downshift Speed <input type="text" value="0"/></p> <p>EXIT MANAGE BACK</p> </div> <div data-bbox="909 1417 1364 1543"> <p>STEP 1</p> <p>Downshift Mode <input type="text" value="MANUAL"/></p> <p>Downshift Torque <input type="text" value="0"/></p> <p>Downshift Speed <input type="text" value="0"/></p> <p>EXIT MANAGE BACK</p> </div> <div data-bbox="868 1575 1356 1711"> <p>STEP 1</p> <p>Downshift Mode <input type="text" value="ATC"/></p> <p>ATC Starting Torque % <input type="text" value="20"/></p> <p>ATC Ending Torque % <input type="text" value="75"/></p> <p>EXIT MANAGE BACK</p> </div> <div data-bbox="909 1722 1364 1848"> <p>STEP 1</p> <p>ATC Starting Torque % <input type="text" value="20"/></p> <p>ATC Ending Torque % <input type="text" value="75"/></p> <p>ATC Ending Speed % <input type="text" value="10"/></p> <p>EXIT MANAGE BACK</p> </div>











Strategy TC/AM Screens	Options Screens
	 
  	     
  	
  	

Alpha Controller





Strategy TC/AM Screens	Options Screens
 <div> STEP 1 Acceleration <input type="text" value="5000"/> Abort Timer <input type="text" value="10"/> Delay Between Steps <input type="text" value="0"/> EXIT MANAGE BACK </div>	
 <div> STEP 1 Abort Timer <input type="text" value="10"/> Delay Between Steps <input type="text" value="0"/> Accumulate Angle <input type="text" value="NO"/> EXIT MANAGE BACK </div>	
 <div> STEP 1 Abort Timer <input type="text" value="10"/> Delay Between Steps <input type="text" value="0"/> Accumulate Angle <input type="text" value="NO"/> EXIT MANAGE BACK </div>	
 <div> STEP 1 Abort Timer <input type="text" value="10"/> Delay Between Steps <input type="text" value="0"/> Accumulate Angle <input type="text" value="NO"/> EXIT MANAGE BACK </div>	 <div> STEP 1 Abort Timer <input type="text" value="10"/> Delay Between Steps <input type="text" value="0"/> Accumulate Angle <input type="text" value="YES"/> OK CANCEL </div>


















2.5.1.4.2 Strategy AC/TM

Strategy AC/TM Screens	Options Screen
Step settings affect only the active Task.	
 <div> AC/TM Name <input type="text"/> Strategy <input type="text" value="AC/TM"/> Snug Torque <input type="text" value="0"/> EXIT MANAGE BACK </div>	 <div> AC/TM Name <input type="text"/> Strategy <input type="text" value="AC/TM"/> Snug Torque <input type="text" value="0"/> OK CANCEL </div>









Strategy AC/TM Screens	Options Screen
  <p>STEP 1</p> <ul style="list-style-type: none"> Snug Torque Angle Target High Angle <p>EXIT MANAGE BACK</p>	
  <p>STEP 1</p> <ul style="list-style-type: none"> Angle Target High Angle Low Angle <p>EXIT MANAGE BACK</p>	
  <p>STEP 1</p> <ul style="list-style-type: none"> High Angle Low Angle High Torque <p>EXIT MANAGE BACK</p>	
  <p>STEP 1</p> <ul style="list-style-type: none"> Low Angle High Torque Low Torque <p>EXIT MANAGE BACK</p>	
  <p>STEP 1</p> <ul style="list-style-type: none"> High Torque Low Torque Torque Bailout <p>EXIT MANAGE BACK</p>	

Alpha Controller







Strategy AC/TM Screens	Options Screen
 <div>STEP 1</div> <div>Low Torque <input type="text" value="0"/></div> <div>Torque Bailout <input type="text" value="9999.9"/></div> <div>Downshift Mode <input type="text" value="DISABLED"/></div> <div>EXIT MANAGE BACK</div>	
 <div>STEP 1</div> <div>Torque Bailout <input type="text" value="9999.9"/></div> <div>Downshift Mode <input type="text" value="DISABLED"/></div> <div>Soft Stop <input type="text" value="YES"/></div> <div>EXIT MANAGE BACK</div>	
 <div>STEP 1</div> <div>Downshift Mode <input type="text" value="DISABLED"/></div> <div>Soft Stop <input type="text" value="YES"/></div> <div>Current Off Time <input type="text" value="0.001"/></div> <div>EXIT MANAGE BACK</div>	 <div>STEP 1</div> <div>Downshift Mode <input type="text" value="DISABLED"/></div> <div>Soft Stop <input type="text" value="MANUAL"/></div> <div>Current Off Time <input type="text" value="0.001"/></div> <div>OK CANCEL</div>
	<div>STEP 1</div> <div>Downshift Mode <input type="text" value="MANUAL"/></div> <div>Downshift Torque <input type="text" value="0"/></div> <div>Downshift Speed <input type="text" value="0"/></div> <div>EXIT MANAGE BACK</div>
	<div>STEP 1</div> <div>Downshift Mode <input type="text" value="MANUAL"/></div> <div>Downshift Torque <input type="text" value="0"/></div> <div>Downshift Speed <input type="text" value="0"/></div> <div>EXIT MANAGE BACK</div>
	<div>STEP 1</div> <div>Downshift Mode <input type="text" value="MANUAL"/></div> <div>Downshift Torque <input type="text" value="0"/></div> <div>Downshift Speed <input type="text" value="0"/></div> <div>EXIT MANAGE BACK</div>
	<div>STEP 1</div> <div>Downshift Mode <input type="text" value="ATC"/></div> <div>ATC Starting Torque % <input type="text" value="20"/></div> <div>ATC Ending Torque % <input type="text" value="75"/></div> <div>EXIT MANAGE BACK</div>
	<div>STEP 1</div> <div>ATC Starting Torque % <input type="text" value="20"/></div> <div>ATC Ending Torque % <input type="text" value="75"/></div> <div>ATC Ending Speed % <input type="text" value="10"/></div> <div>EXIT MANAGE BACK</div>
	<div>STEP 1</div> <div>ATC Starting Torque % <input type="text" value="20"/></div> <div>ATC Ending Torque % <input type="text" value="75"/></div> <div>ATC Ending Speed % <input type="text" value="10"/></div> <div>EXIT MANAGE BACK</div>











Strategy AC/TM Screens	Options Screen
  	       
  	
  	

Alpha Controller





Strategy AC/TM Screens	Options Screen
 	
 	
 	 

2.5.1.4.3 Strategy AC/TC

Strategy AC/TC Screens	Options Screen
Step settings affect only the active <u>Task</u> .	
 	 
 	

Strategy AC/TC Screens	Options Screen
  <p>STEP 1</p> <ul style="list-style-type: none"> High Torque 9999.9 Low Torque 0 Torque Bailout 9999.9 <p>EXIT MANAGE BACK</p>	
  <p>STEP 1</p> <ul style="list-style-type: none"> Low Torque 0 Torque Bailout 9999.9 Snug Torque 0 <p>EXIT MANAGE BACK</p>	
  <p>STEP 1</p> <ul style="list-style-type: none"> Torque Bailout 9999.9 Snug Torque 0 Angle Target 0 <p>EXIT MANAGE BACK</p>	
  <p>STEP 1</p> <ul style="list-style-type: none"> Snug Torque 0 Angle Target 0 High Angle 9999.9 <p>EXIT MANAGE BACK</p>	
  <p>STEP 1</p> <ul style="list-style-type: none"> Angle Target 0 High Angle 9999.9 Low Angle 0 <p>EXIT MANAGE BACK</p>	

Alpha Controller

Strategy AC/TC Screens	Options Screen
 <div>STEP 1</div> <div>High Angle 9999.9</div> <div>Low Angle 0</div> <div>Angle Bailout 9999.9</div> <div>EXIT MANAGE BACK</div>	
 <div>STEP 1</div> <div>Low Angle 0</div> <div>Angle Bailout 9999.9</div> <div>Downshift Mode DISABLED</div> <div>EXIT MANAGE BACK</div>	
 <div>STEP 1</div> <div>Angle Bailout 9999.9</div> <div>Downshift Mode DISABLED</div> <div>Soft Stop YES</div> <div>EXIT MANAGE BACK</div>	
 <div>STEP 1</div> <div>Downshift Mode MANUAL</div> <div>Downshift Torque 0</div> <div>Downshift Speed 0</div> <div>EXIT MANAGE BACK</div>	 <div>STEP 1</div> <div>Downshift Mode DISABLED</div> <div>Soft Stop MANUAL</div> <div>Current Off Time 0.001</div> <div>OK CANCEL</div>
	<div>STEP 1</div> <div>Downshift Mode DISABLED</div> <div>Soft Stop YES</div> <div>Current Off Time 0.001</div> <div>EXIT MANAGE BACK</div>
	<div>STEP 1</div> <div>Downshift Mode MANUAL</div> <div>Downshift Torque 0</div> <div>Downshift Speed 0</div> <div>EXIT MANAGE BACK</div>
	<div>STEP 1</div> <div>Downshift Mode MANUAL</div> <div>Downshift Torque 0</div> <div>Downshift Speed 0</div> <div>EXIT MANAGE BACK</div>

Strategy AC/TC Screens

Options Screen



STEP 1

Soft Stop YES

Current Off Time 0.001

Current Hold Time 0.025

EXIT MANAGE BACK



STEP 1

Soft Stop NO

Current Off Time YES

Current Hold Time 0.025

OK CANCEL

STEP 1

Soft Stop YES

Current Off Time 0.001

Current Hold Time 0.025

EXIT MANAGE BACK

STEP 1

Soft Stop YES

Current Off Time 0.001

Current Hold Time 0.025

EXIT MANAGE BACK

STEP 1

Current Off Time 0.001

Current Hold Time 0.025

Current Ramp Time 0.075

EXIT MANAGE BACK

STEP 1

Soft Stop NO

Speed 9999

Power 100

EXIT MANAGE BACK

STEP 1

Downshift Mode MANUAL

Downshift Torque 0

Downshift Speed 0

EXIT MANAGE BACK

STEP 1

Downshift Mode ATC

ATC Starting Torque % 20

ATC Ending Torque % 75

EXIT MANAGE BACK

STEP 1

ATC Starting Torque % 20

ATC Ending Torque % 75

ATC Ending Speed % 10

EXIT MANAGE BACK

STEP 1

ATC Starting Torque % 20

ATC Ending Torque % 75

ATC Ending Speed % 10

EXIT MANAGE BACK

STEP 1

ATC Starting Torque % 20

ATC Ending Torque % 75

ATC Ending Speed % 10

EXIT MANAGE BACK

Alpha Controller

Strategy AC/TC Screens	Options Screen
 	
 	
 	
 	
 	 

2.5.1.4.4 Strategy BACK (Backoff)

Strategy BACK (Backoff) Screens	Options Screen
Step settings affect only the active Task.	
  <div data-bbox="349 388 836 525"> <p>STEP 1</p> <p>Name <input type="text"/> STEP 1</p> <p>Strategy <input type="text"/> BACK</p> <p>-Snug Torque <input type="text"/> 0</p> <p>EXIT MANAGE BACK</p> </div>	  <div data-bbox="876 388 1364 525"> <p>STEP 1</p> <p>Name <input type="text"/></p> <p>Strategy <input type="text"/></p> <p>-Torque Target <input type="text"/></p> <p>TCAM ACTM ACTC BACK OK CANCEL</p> </div>
  <div data-bbox="349 682 836 819"> <p>STEP 1</p> <p>-Snug Torque <input type="text"/> 0</p> <p>-Angle Target <input type="text"/> 0</p> <p>-High Angle <input type="text"/> 9999.9</p> <p>EXIT MANAGE BACK</p> </div>	
  <div data-bbox="349 976 836 1113"> <p>STEP 1</p> <p>-Angle Target <input type="text"/> 0</p> <p>-High Angle <input type="text"/> 9999.9</p> <p>-Low Angle <input type="text"/> 0</p> <p>EXIT MANAGE BACK</p> </div>	
  <div data-bbox="349 1270 836 1407"> <p>STEP 1</p> <p>-Low Angle <input type="text"/> 0</p> <p>-Torque Target <input type="text"/> 17.5</p> <p>-High Torque <input type="text"/> 35</p> <p>EXIT MANAGE BACK</p> </div>	
  <div data-bbox="349 1564 836 1701"> <p>STEP 1</p> <p>-Low Angle <input type="text"/> 0</p> <p>-Torque Target <input type="text"/> 0</p> <p>-High Torque <input type="text"/> 9999.9</p> <p>MANAGE BACK</p> </div>	

Alpha Controller

Strategy BACK (Backoff) Screens	Options Screen
   <div> STEP 1 Torque Target <input type="text" value="0"/> High Torque <input type="text" value="9999.9"/> Low Torque <input type="text" value="0"/> EXIT MANAGE BACK </div>	
   <div> STEP 1 High Torque <input type="text" value="9999.9"/> Low Torque <input type="text" value="0"/> Torque Bailout <input type="text" value="9999.9"/> EXIT MANAGE BACK </div>	
   <div> STEP 1 Low Torque <input type="text" value="0"/> Torque Bailout <input type="text" value="9999.9"/> Downshift Mode <input type="text" value="DISABLED"/> EXIT MANAGE BACK </div>	
   <div> STEP 1 Torque Bailout <input type="text" value="9999.9"/> Downshift Mode <input type="text" value="DISABLED"/> Soft Stop <input type="text" value="YES"/> EXIT MANAGE BACK </div>	
   <div> STEP 1 Downshift Mode <input type="text" value="MANUAL"/> Downshift Torque <input type="text" value="0"/> Downshift Speed <input type="text" value="0"/> EXIT MANAGE BACK </div>	  <div> STEP 1 Downshift Mode <input type="text" value="DISABLED"/> Soft Stop <input type="text" value="MANUAL"/> Current Off Time <input type="text" value="0.001"/> OK CANCEL </div> <div> STEP 1 Downshift Mode <input type="text" value="DISABLED"/> Soft Stop <input type="text" value="YES"/> Current Off Time <input type="text" value="0.001"/> EXIT MANAGE BACK </div>

Strategy BACK (Backoff) Screens

Options Screen



STEP 1

Soft Stop ☐ YES

Current Off Time

Current Hold Time

EXIT MANAGE BACK



STEP 1

Speed

Power

Acceleration

EXIT MANAGE BACK



STEP 1

Soft Stop ☐ NO

Current Off Time

Current Hold Time

Current Ramp Time

EXIT MANAGE BACK

STEP 1

Current Off Time

Current Hold Time

Current Ramp Time

EXIT MANAGE BACK

STEP 1

Soft Stop ☐ YES

Current Off Time

Current Hold Time

EXIT MANAGE BACK

STEP 1

Current Off Time

Current Hold Time

Current Ramp Time

EXIT MANAGE BACK

STEP 1

Soft Stop ☐ NO

Speed

Power

EXIT MANAGE BACK

Alpha Controller

Strategy BACK (Backoff) Screens	Options Screen
 	
 	
 	
 	
 	 

2.5.1.4.5 Strategy AC/TA

Strategy AC/TA Screens	Options Screen
Step settings affect only the active <u>Task</u> . Torque rate strategy (<u>Torque Average</u> and <u>Angle Interval</u>) configuration is set in the <u>Task</u> tab.	
 <p>AC/TA Strategy Selection Screen. Fields: Name, Strategy (AC/TA), Snug Torque (0). Buttons: EXIT, MANAGE, BACK.</p>	 <p>AC/TM Strategy Selection Screen. Fields: Name, Strategy (AC/TM), Snug Torque. Buttons: OK, CANCEL.</p>
 <p>STEP 1 Snug Torque and Angle Target Screen. Fields: Snug Torque, Angle Target, High Angle (9999.9). Buttons: EXIT, MANAGE, BACK.</p>	
 <p>STEP 1 Angle Target and High/Low Angle Screen. Fields: Angle Target, High Angle (9999.9), Low Angle (0). Buttons: EXIT, MANAGE, BACK.</p>	
 <p>STEP 1 High/Low Angle and High Torque Screen. Fields: High Angle (9999.9), Low Angle (0), High Torque (9999.9). Buttons: EXIT, MANAGE, BACK.</p>	
 <p>STEP 1 Low Angle and High/Low Torque Screen. Fields: Low Angle, High Torque (9999.9), Low Torque (0). Buttons: EXIT, MANAGE, BACK.</p>	

Alpha Controller


Strategy AC/TA Screens	Options Screen
 <div>STEP 1</div> <div>High Torque <input type="text" value="35"/></div> <div>Low Torque <input type="text" value="0"/></div> <div>Max Torque Bailout <input type="text" value="9999.9"/></div> <div>EXIT MANAGE BACK</div>	
 <div>STEP 1</div> <div>Low Torque <input type="text" value="0"/></div> <div>Max Torque Bailout <input type="text" value="9999.9"/></div> <div>Min Torque Bailout <input type="text" value="0"/></div> <div>EXIT MANAGE BACK</div>	
 <div>STEP 1</div> <div>Max Torque Bailout <input type="text" value="9999.9"/></div> <div>Min Torque Bailout <input type="text" value="0"/></div> <div>Downshift Mode <input type="text" value="MANUAL"/></div> <div>EXIT MANAGE BACK</div>	
 <div>AC/TA</div> <div>Min Torque Bailout <input type="text" value="0"/></div> <div>Accumulate Torque <input type="text" value="NO"/></div> <div>Downshift Mode <input type="text" value="ATC"/></div> <div>EXIT MANAGE BACK</div>	
 <div>AC/TA</div> <div>Accumulate Torque <input type="text" value="NO"/></div> <div>Downshift Mode <input type="text" value="ATC"/></div> <div>ATC Starting Torque % <input type="text" value="20"/></div> <div>EXIT MANAGE BACK</div>	 <div>AC/TA</div> <div>Accumulate Torque <input type="text" value="NO"/></div> <div>Downshift Mode <input type="text" value="ATC"/></div> <div>ATC Starting Torque % <input type="text" value="20"/></div> <div>OK CANCEL</div>
 <div>STEP 1</div> <div>Downshift Mode <input type="text" value="MANUAL"/></div> <div>Downshift Torque <input type="text" value="0"/></div> <div>Downshift Speed <input type="text" value="0"/></div> <div>EXIT MANAGE BACK</div>	 <div>STEP 1</div> <div>Downshift Mode <input type="text" value="DISABLED"/></div> <div>Soft Stop <input type="text" value="MANUAL"/></div> <div>Current Off Time <input type="text" value="0.001"/></div> <div>OK CANCEL</div>

Strategy AC/TA Screens

Options Screen

	<div data-bbox="873 243 1362 380"> <p>STEP 1</p> <p>Downshift Mode DISABLED</p> <p>Soft Stop YES</p> <p>Current Off Time 0.001</p> <p>EXIT MANAGE BACK</p> </div> <div data-bbox="873 426 1362 562"> <p>STEP 1</p> <p>Downshift Mode MANUAL</p> <p>Downshift Torque 0</p> <p>Downshift Speed 0</p> <p>EXIT MANAGE BACK</p> </div> <div data-bbox="902 569 1362 705"> <p>STEP 1</p> <p>Downshift Mode MANUAL</p> <p>Downshift Torque 0</p> <p>Downshift Speed 0</p> <p>EXIT MANAGE BACK</p> </div> <div data-bbox="902 709 1362 840"> <p>STEP 1</p> <p>Downshift Mode MANUAL</p> <p>Downshift Torque 0</p> <p>Downshift Speed 0</p> <p>EXIT MANAGE BACK</p> </div>
<div data-bbox="344 840 511 934"> </div> <div data-bbox="344 934 836 1081"> <p>STEP 1</p> <p>Soft Stop YES</p> <p>Current Off Time 0.001</p> <p>Current Hold Time 0.025</p> <p>EXIT MANAGE BACK</p> </div>	<div data-bbox="873 840 1040 934"> </div> <div data-bbox="873 934 1362 1081"> <p>STEP 1</p> <p>Soft Stop NO</p> <p>Current Off Time 0.001</p> <p>Current Hold Time 0.025</p> <p>OK CANCEL</p> </div> <div data-bbox="902 1081 1362 1218"> <p>STEP 1</p> <p>Current Off Time 0.001</p> <p>Current Hold Time 0.025</p> <p>Current Ramp Time 0.075</p> <p>EXIT MANAGE BACK</p> </div> <div data-bbox="902 1218 1362 1354"> <p>STEP 1</p> <p>Soft Stop YES</p> <p>Current Off Time 0.001</p> <p>Current Hold Time 0.025</p> <p>EXIT MANAGE BACK</p> </div> <div data-bbox="902 1354 1362 1491"> <p>STEP 1</p> <p>Current Off Time 0.001</p> <p>Current Hold Time 0.025</p> <p>Current Ramp Time 0.075</p> <p>EXIT MANAGE BACK</p> </div> <div data-bbox="873 1491 1362 1633"> <p>STEP 1</p> <p>Soft Stop NO</p> <p>Speed 9999</p> <p>Power 100</p> <p>EXIT MANAGE BACK</p> </div>
<div data-bbox="344 1633 625 1774"> </div> <div data-bbox="344 1774 836 1919"> <p>STEP 1</p> <p>Speed 9999</p> <p>Power 100</p> <p>Acceleration 3000</p> <p>EXIT MANAGE BACK</p> </div>	

Alpha Controller

Strategy AC/TA Screens	Options Screen
 	
 	
 	
 	
 	 

2.5.1.4.6 Strategy RC/AM

Strategy RC/AM Screens	Options Screen
Step settings affect only the active <u>Task</u> . Torque rate strategy (<u>Torque Average</u> and <u>Angle Interval</u>) configuration is set in the <u>Task</u> tab.	
 <p>RC/AM Strategy Selection Screen. Fields: Name, Strategy (RC/AM), Torque Rate Target (0). Buttons: EXIT, MANAGE, BACK.</p>	 <p>AC/TM Strategy Selection Screen. Fields: Name, Strategy (AC/TM), Snug Torque. Buttons: OK, CANCEL.</p>
 <p>STEP 1 Torque Rate Target Screen. Fields: Torque Rate Target (0), High Torque (35), Low Torque (0). Buttons: EXIT, MANAGE, BACK.</p>	
 <p>STEP 1 High Torque Screen. Fields: High Torque (9999.9), Low Torque (0), Torque Bailout (9999.9). Buttons: EXIT, MANAGE, BACK.</p>	
 <p>STEP 1 Torque Bailout Screen. Fields: Low Torque (0), Torque Bailout (9999.9), Snug Torque (0). Buttons: EXIT, MANAGE, BACK.</p>	
 <p>STEP 1 Snug Torque Screen. Fields: Torque Bailout (9999.9), Snug Torque (8.75), High Angle (9999.9). Buttons: EXIT, MANAGE, BACK.</p>	

Alpha Controller

Strategy RC/AM Screens	Options Screen
   <div> STEP 1 Snug Torque <input type="text" value="0"/> High Angle <input type="text" value="9999.9"/> Low Angle <input type="text" value="0"/> EXIT MANAGE BACK </div>	
   <div> STEP 1 High Angle <input type="text" value="9999.9"/> Low Angle <input type="text" value="0"/> Angle Bailout <input type="text" value="9999.9"/> EXIT MANAGE BACK </div>	
   <div> STEP 1 Low Angle <input type="text" value="0"/> Angle Bailout <input type="text" value="9999.9"/> Downshift Mode <input type="text" value="DISABLED"/> EXIT MANAGE BACK </div>	
   <div> STEP 1 Angle Bailout <input type="text" value="9999.9"/> Downshift Mode <input type="text" value="DISABLED"/> Soft Stop <input type="text" value="YES"/> EXIT MANAGE BACK </div>	
   <div> STEP 1 Downshift Mode <input type="text" value="MANUAL"/> Downshift Torque <input type="text" value="0"/> Downshift Speed <input type="text" value="0"/> EXIT MANAGE BACK </div>	  <div> STEP 1 Downshift Mode <input type="text" value="DISABLED"/> Soft Stop <input type="text" value="MANUAL"/> Current Off Time <input type="text" value="0.001"/> OK CANCEL </div> <div> STEP 1 Downshift Mode <input type="text" value="DISABLED"/> Soft Stop <input type="text" value="YES"/> Current Off Time <input type="text" value="0.001"/> EXIT MANAGE BACK </div>

Strategy RC/AM Screens

Options Screen



STEP 1

Soft Stop ☐ YES

Current Off Time

Current Hold Time

EXIT MANAGE BACK



STEP 1

Speed

Power

Acceleration

EXIT MANAGE BACK



STEP 1

Soft Stop ☐ NO

Current Off Time

Current Hold Time

Current Ramp Time

EXIT MANAGE BACK

STEP 1

Current Off Time

Current Hold Time

Current Ramp Time

EXIT MANAGE BACK

STEP 1

Soft Stop ☐ YES

Current Off Time

Current Hold Time

EXIT MANAGE BACK

STEP 1

Current Off Time

Current Hold Time

Current Ramp Time

EXIT MANAGE BACK

STEP 1

Soft Stop ☐ NO

Speed

Power

EXIT MANAGE BACK

Alpha Controller

Strategy RC/AM Screens	Options Screen
 	
 	
 	
 	
 	 

2.5.1.4.7 Strategy YC/AM

Strategy YC/AM Screens	Options Screen
Step settings affect only the active <u>Task</u> . Torque rate strategy (<u>Torque Average</u> and <u>Angle Interval</u>) configuration is set in the <u>Task</u> tab.	
  	  
   	
   	
   	
   	

Alpha Controller

Strategy YC/AM Screens	Options Screen
 <div>STEP 1</div> <div>Snug Torque <input type="text" value="0"/></div> <div>High Angle <input type="text" value="9999.9"/></div> <div>Low Angle <input type="text" value="0"/></div> <div>EXIT MANAGE BACK</div>	
 <div>STEP 1</div> <div>High Angle <input type="text" value="9999.9"/></div> <div>Low Angle <input type="text" value="0"/></div> <div>Angle Bailout <input type="text" value="9999.9"/></div> <div>EXIT MANAGE BACK</div>	
 <div>STEP 1</div> <div>Low Angle <input type="text" value="0"/></div> <div>Angle Bailout <input type="text" value="9999.9"/></div> <div>Downshift Mode <input type="text" value="DISABLED"/></div> <div>EXIT MANAGE BACK</div>	
 <div>STEP 1</div> <div>Angle Bailout <input type="text" value="9999.9"/></div> <div>Downshift Mode <input type="text" value="DISABLED"/></div> <div>Soft Stop <input type="text" value="YES"/></div> <div>EXIT MANAGE BACK</div>	
 <div>STEP 1</div> <div>Downshift Mode <input type="text" value="MANUAL"/></div> <div>Downshift Torque <input type="text" value="0"/></div> <div>Downshift Speed <input type="text" value="0"/></div> <div>EXIT MANAGE BACK</div>	 <div>STEP 1</div> <div>Downshift Mode <input type="text" value="DISABLED"/></div> <div>Soft Stop <input type="text" value="MANUAL"/></div> <div>Current Off Time <input type="text" value="0.001"/></div> <div>OK CANCEL</div>
	<div>STEP 1</div> <div>Downshift Mode <input type="text" value="DISABLED"/></div> <div>Soft Stop <input type="text" value="YES"/></div> <div>Current Off Time <input type="text" value="0.001"/></div> <div>EXIT MANAGE BACK</div>

Strategy YC/AM Screens

Options Screen



STEP 1

Soft Stop YES

Current Off Time 0.001

Current Hold Time 0.025

EXIT MANAGE BACK



STEP 1

Speed 9999

Power 100

Acceleration 3000

EXIT MANAGE BACK



STEP 1

Soft Stop NO

Current Off Time 0.001

Current Hold Time 0.025

OK CANCEL

STEP 1

Current Off Time 0.001

Current Hold Time 0.025

Current Ramp Time 0.075

EXIT MANAGE BACK

STEP 1

Soft Stop YES

Current Off Time 0.001

Current Hold Time 0.025

EXIT MANAGE BACK

STEP 1

Current Off Time 0.001

Current Hold Time 0.025

Current Ramp Time 0.075

EXIT MANAGE BACK

STEP 1

Soft Stop NO

Speed 9999

Power 100

EXIT MANAGE BACK






Alpha Controller














Strategy YC/AM Screens	Options Screen
 <div data-bbox="349 357 836 493"> <p>STEP 1</p> <p>Power <input type="text" value="100"/></p> <p>Acceleration <input type="text" value="3000"/></p> <p>Abort Timer <input type="text" value="10"/></p> <p>EXIT MANAGE BACK</p> </div>	
 <div data-bbox="349 651 836 787"> <p>STEP 1</p> <p>Acceleration <input type="text" value="3000"/></p> <p>Abort Timer <input type="text" value="10"/></p> <p>Delay Between Steps <input type="text" value="0"/></p> <p>EXIT MANAGE BACK</p> </div>	
 <div data-bbox="349 945 836 1081"> <p>STEP 1</p> <p>Abort Timer <input type="text" value="10"/></p> <p>Delay Between Steps <input type="text" value="0"/></p> <p>Accumulate Angle <input type="text" value="NO"/></p> <p>EXIT MANAGE BACK</p> </div>	
 <div data-bbox="349 1239 836 1375"> <p>STEP 1</p> <p>Abort Timer <input type="text" value="10"/></p> <p>Delay Between Steps <input type="text" value="0"/></p> <p>Accumulate Angle <input type="text" value="NO"/></p> <p>EXIT MANAGE BACK</p> </div>	
 <div data-bbox="349 1486 836 1623"> <p>STEP 1</p> <p>Abort Timer <input type="text" value="10"/></p> <p>Delay Between Steps <input type="text" value="0"/></p> <p>Accumulate Angle <input type="text" value="NO"/></p> <p>EXIT MANAGE BACK</p> </div>	 <div data-bbox="876 1486 1364 1623"> <p>STEP 1</p> <p>Abort Timer <input type="text" value="10"/></p> <p>Delay Between Steps <input type="text" value="0"/></p> <p>Accumulate Angle <input type="text" value="NO"/></p> <p>OK CANCEL</p> </div>

2.5.1.4.8 Strategy BACKOFF






Strategy BACKOFF Screens	Options Screen
Step settings affect only the active <u>Task</u> . Torque rate strategy (<u>Torque Average</u> and <u>Angle Interval</u>) configuration is set in the <u>Task</u> tab.	
  	  
  	
  	
  	
  	

Alpha Controller



Strategy BACKOFF Screens	Options Screen
 <div> <div>BACK OFF</div> <div>High Torque 9999.9</div> <div>Low Torque 0</div> <div>Torque Bailout 9999.9</div> <div>EXIT MANAGE BACK</div> </div>	
 <div> <div>BACK OFF</div> <div>Low Torque 0</div> <div>Torque Bailout 9999.9</div> <div>Downshift Mode ATC</div> <div>EXIT MANAGE BACK</div> </div>	
 <div> <div>BACK OFF</div> <div>Torque Bailout 9999.9</div> <div>Downshift Mode ATC</div> <div>ATC Starting Torque % 20</div> <div>EXIT MANAGE BACK</div> </div>	
 <div> <div>STEP 1</div> <div>Downshift Mode MANUAL</div> <div>Downshift Torque 0</div> <div>Downshift Speed 0</div> <div>EXIT MANAGE BACK</div> </div>	 <div> <div>STEP 1</div> <div>Downshift Mode DISABLED</div> <div>Soft Stop MANUAL</div> <div>Current Off Time 0.001</div> <div>OK CANCEL</div> </div>
	<div> <div>STEP 1</div> <div>Downshift Mode DISABLED</div> <div>Soft Stop YES</div> <div>Current Off Time 0.001</div> <div>EXIT MANAGE BACK</div> </div>
	<div> <div>STEP 1</div> <div>Downshift Mode MANUAL</div> <div>Downshift Torque 0</div> <div>Downshift Speed 0</div> <div>EXIT MANAGE BACK</div> </div>
	<div> <div>STEP 1</div> <div>Downshift Mode MANUAL</div> <div>Downshift Torque 0</div> <div>Downshift Speed 0</div> <div>EXIT MANAGE BACK</div> </div>


Strategy BACKOFF Screens	Options Screen
 	      
 	
 	

Alpha Controller

Strategy BACKOFF Screens	Options Screen
	
	
	
	

2.5.1.5 Setup: Manage

Manage Screens	Options Screen
	



2.5.1.6 Setup: Exit


Exit Screens	Options Screen
Programming changes are stored after exiting current menu.	

2.5.2 Setup Menu: 2. Communications

Communication Screens	Options Screen
Programming changes are stored after exiting current menu.	

Alpha Controller

Communication Screens



TCP/IP SERIAL RFCS OPEN TC

Obtain IP From Network YES

IP Address ...

Subnet Mask ...

EXIT



TCP/IP SERIAL RFCS OPEN TC

COM Port 1 ETB

COM Port 2 BARCODE/PRINTER

EXIT




TCP/IP SERIAL RFCS OPEN TC

COM Port 1 ETB

COM Port 2 BARCODE/PRINTER

EXIT

Options Screen



1 2 3
4 5 6
7 8 9
0

TCP/IP SERIAL RFCS OPEN TC

Obtain IP From Network NO

IP Address YES

Subnet Mask ...

OK CANCEL

TCP/IP SERIAL RFCS OPEN TC

Obtain IP From Network NO

IP Address

Subnet Mask

EXIT

TCP/IP SERIAL RFCS OPEN TC

IP Address

Subnet Mask

Gateway

OK CANCEL

TCP/IP SERIAL RFCS OPEN TC

Subnet Mask

Gateway

DNS

OK CANCEL

TCP/IP SERIAL RFCS OPEN TC

Gateway

DNS

Physical

OK CANCEL

TCP/IP SERIAL RFCS OPEN TC

Gateway

DNS

Physical

OK CANCEL

TCP/IP SERIAL RFCS OPEN TC

DNS

Physical

Master IP

EXIT




TCP/IP SERIAL RFCS OPEN TC

COM Port 1 BARCODE/PRINTER

COM Port 2 BARCODE/PRINTER

ETB

OK CANCEL














TCP/IP SERIAL RFCS OPEN TC

COM Port 1 BARCODE/PRINTER

COM Port 2 BARCODE/PRINTER


TOYOTA

OK CANCEL









Communication Screens	Options Screen
	
 	
 	
 	
 	
 	

Alpha Controller

Communication Screens	Options Screen
 <div data-bbox="349 357 836 493"> <div>TCP/IP SERIAL PFCS OPEN TC</div> <div>Cell 1</div> <div>Buffer While Off Line NO</div> <div>Send Fastener Removed YES</div> <div>EXIT</div> </div>	 <div data-bbox="876 357 1364 493"> <div>TCP/IP SERIAL PFCS OPEN TC</div> <div>Cell 1</div> <div>Buffer While Off Line NO</div> <div>Send Fastener Removed YES</div> <div>OK CANCEL</div> </div>
 <div data-bbox="349 651 836 787"> <div>TCP/IP SERIAL PFCS OPEN TC</div> <div>Cell 1</div> <div>Buffer While Off Line NO</div> <div>Send Fastener Removed YES</div> <div>EXIT</div> </div>	 <div data-bbox="876 651 1364 787"> <div>TCP/IP SERIAL PFCS OPEN TC</div> <div>Cell 1</div> <div>Buffer While Off Line NO</div> <div>Send Fastener Removed YES</div> <div>OK CANCEL</div> </div>
 <div data-bbox="349 945 836 1039"> <div>SERIAL PFCS OPEN TOOLSNET</div> <div>Server IP</div> <div>Port 6547</div> <div>Cell 1</div> <div>OK CANCEL</div> </div>	
 <div data-bbox="349 1197 836 1333"> <div>SERIAL PFCS OPEN TOOLSNET</div> <div>Port 6547</div> <div>Cell 1</div> <div>Station 1</div> <div>EXIT</div> </div>	
 <div data-bbox="349 1491 836 1627"> <div>SERIAL PFCS OPEN TOOLSNET</div> <div>Port 6547</div> <div>Cell 1</div> <div>Station 1</div> <div>EXIT</div> </div>	
 <div data-bbox="349 1785 836 1923"> <div>SERIAL PFCS OPEN TOOLSNET</div> <div>Port 6547</div> <div>Cell 1</div> <div>Station 1</div> <div>EXIT</div> </div>	


Communication Screens	Options Screen
	

2.5.3 Setup Menu: 3. Other

Other Screens	Options Screen
Programming changes are stored after exiting current menu.	
	
	
	
	
	






MANAGE



Other Screens

Options Screen





GENERAL	USERS	OUTPUTS	INPUTS
OFF			(E)
OFF			(F)
OFF			(G)
EXIT		CONFIG	



GENERAL	USERS	OUTPUTS	INPUTS
OFF			(E)
IN CYCLE			(F)
JOB SELECTED			(G)
DISASSEMBLY DETECTED			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
TOOL RUNNING			(E)
CYCLE OK			(F)
CYCLE NOK			(G)
TASK SELECTED			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
JOB COMPLETE			(E)
TASK COMPLETE			(F)
TASK SELECTED BIT			(G)
JOB SELECTED BIT			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
TORQUE OK			(E)
TORQUE HI			(F)
TORQUE LOW			(G)
ANGLE OK			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
ANGLE HI			(E)
ANGLE LOW			(F)
CYCLE ABORTED			(G)
STOPPED			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
FAULTED			(E)
READY			(F)
PM			(G)
START TRIGGER			
OK		CANCEL	

Other Screens

Options Screen



GENERAL	USERS	OUTPUTS	INPUTS
OFF		(F)	
OFF		(G)	
OFF		(H)	
EXIT		CONFIG	



GENERAL	USERS	OUTPUTS	INPUTS
OFF		(G)	
OFF		(H)	
OFF		(J)	
EXIT		CONFIG	



GENERAL	USERS	OUTPUTS	INPUTS
OFF		(F)	
IN CYCLE		(G)	
JOB SELECTED		(H)	
DISASSEMBLY DETECTED			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
TOOL RUNNING		(F)	
CYCLE OK		(G)	
CYCLE NOK		(H)	
TASK SELECTED			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
JOB COMPLETE		(F)	
TASK COMPLETE		(G)	
TASK SELECTED BIT		(H)	
JOB SELECTED BIT			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
TORQUE OK		(F)	
TORQUE HI		(G)	
TORQUE LOW		(H)	
ANGLE OK			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
ANGLE HI		(F)	
ANGLE LOW		(G)	
CYCLE ABORTED		(H)	
STOPPED			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
FAULTED		(F)	
READY		(G)	
PM		(H)	
START TRIGGER			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
MFB		(F)	
SNUG ACHIEVED		(G)	
CYCLE STOPPED		(H)	
STEP BIT			
OK		CANCEL	



GENERAL	USERS	OUTPUTS	INPUTS
OFF		(G)	
IN CYCLE		(H)	
JOB SELECTED		(J)	
DISASSEMBLY DETECTED			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
TOOL RUNNING		(G)	
CYCLE OK		(H)	
CYCLE NOK		(J)	
TASK SELECTED			
OK		CANCEL	



GENERAL	USERS	OUTPUTS	INPUTS
OFF		(H)	
OFF		(J)	
OFF		(K)	
<div>EXIT</div> <div>CONFIG</div>			



GENERAL	USERS	OUTPUTS	INPUTS
OFF		(H)	
IN CYCLE		(J)	
JOB SELECTED		(K)	
<div>OK</div> <div>CANCEL</div>			

GENERAL	USERS	OUTPUTS	INPUTS
TOOL RUNNING		(H)	
CYCLE OK		(J)	
CYCLE NOK		(K)	
<div>OK</div> <div>CANCEL</div>			

GENERAL	USERS	OUTPUTS	INPUTS
JOB COMPLETE		(H)	
TASK COMPLETE		(J)	
TASK SELECTED BIT		(K)	
<div>OK</div> <div>CANCEL</div>			

GENERAL	USERS	OUTPUTS	INPUTS
TORQUE OK		(H)	
TORQUE HI		(J)	
TORQUE LOW		(K)	
<div>OK</div> <div>CANCEL</div>			

GENERAL	USERS	OUTPUTS	INPUTS
ANGLE HI		(H)	
ANGLE LOW		(J)	
CYCLE ABORTED		(K)	
<div>OK</div> <div>CANCEL</div>			

GENERAL	USERS	OUTPUTS	INPUTS
FAULTED		(H)	
READY		(J)	
PM		(K)	
<div>OK</div> <div>CANCEL</div>			

Other Screens

Options Screen



GENERAL	USERS	OUTPUTS	INPUTS	TF
OFF (H)				
OFF (J)				
OFF (K)				
EXIT		CONFIG		



GENERAL	USERS	OUTPUTS	INPUTS	TF
OFF (H)				
OFF (J)				
OFF (K)				
EXIT		CONFIG		



GENERAL	USERS	OUTPUTS	INPUTS	TF
MFB				
SNUG ACHIEVED				
CYCLE STOPPED				
STEP BIT				
OK		CANCEL		

GENERAL	USERS	OUTPUTS	INPUTS	TF
OFF				
IN CYCLE				
JOB SELECTED				
DISASSEMBLY DETECTED				
OK		CANCEL		

GENERAL	USERS	OUTPUTS	INPUTS	TF
TOOL RUNNING				
CYCLE OK				
CYCLE NOK				
TASK SELECTED				
OK		CANCEL		

GENERAL	USERS	OUTPUTS	INPUTS	TF
JOB COMPLETE				
TASK COMPLETE				
TASK SELECTED BIT				
JOB SELECTED BIT				
OK		CANCEL		

GENERAL	USERS	OUTPUTS	INPUTS	TF
TORQUE OK				
TORQUE HI				
TORQUE LOW				
ANGLE OK				
OK		CANCEL		

GENERAL	USERS	OUTPUTS	INPUTS	TF
ANGLE HI				
ANGLE LOW				
CYCLE ABORTED				
STOPPED				
OK		CANCEL		

GENERAL	USERS	OUTPUTS	INPUTS	TF
FAULTED				
READY				
PM				
START TRIGGER				
OK		CANCEL		



GENERAL	USERS	OUTPUTS	INPUTS	TF
OFF				
IN CYCLE				
JOB SELECTED				
DISASSEMBLY DETECTED				
OK		CANCEL		

GENERAL	USERS	OUTPUTS	INPUTS	TF
TOOL RUNNING				
CYCLE OK				
CYCLE NOK				
TASK SELECTED				
OK		CANCEL		



GENERAL	USERS	OUTPUTS	INPUTS
L		IGNORE	
M		IGNORE	
N		IGNORE	
EXIT		CONFIG	



GENERAL	USERS	OUTPUTS	INPUTS
L		IGNORE	
M		START	
N		SELECT JOB	
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
L		STOP	
M		RESET JOB	
N		TASK SELECT BIT	
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
L		REVERSE	
M		DISABLE TASK	
N		DISABLE JOB	
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
L		JOB VERIFY	
M		TASK VERIFY BIT	
N		JOB VERIFY BIT	
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
L		JOB VERIFY BIT	
M		RESET RESULT STATUS	
N		REVERSE START	
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
JOB COMPLETE			
TASK COMPLETE			
TASK SELECTED BIT			
JOB SELECTED BIT			
OK		CANCEL	


GENERAL	USERS	OUTPUTS	INPUTS
TORQUE OK			
TORQUE HI			
TORQUE LOW			
ANGLE OK			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
ANGLE HI			
ANGLE LOW			
CYCLE ABORTED			
STOPPED			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
FAULTED			
READY			
PM			
START TRIGGER			
OK		CANCEL	

GENERAL	USERS	OUTPUTS	INPUTS
MFB			
SNUG ACHIEVED			
CYCLE STOPPED			
STEP BIT			
OK		CANCEL	

Other Screens



GENERAL		USERS	OUTPUTS	INPUTS
M				IGNORE
N				IGNORE
P				IGNORE

EXIT CONFIG

Options Screen



GENERAL		USERS	OUTPUTS	INPUTS
M				IGNORE
N				START
P				SELECT JOB
				SELECT TASK

OK CANCEL

GENERAL		USERS	OUTPUTS	INPUTS
M				STOP
N				RESET JOB
P				TASK SELECT BIT
				JOB SELECT BIT

OK CANCEL

GENERAL		USERS	OUTPUTS	INPUTS
M				REVERSE
N				DISABLE TASK
P				DISABLE JOB
				TASK VERIFY


OK CANCEL

GENERAL		USERS	OUTPUTS	INPUTS
M				JOB VERIFY
N				TASK VERIFY BIT
P				JOB VERIFY BIT
				RESET RESULT STATUS

OK CANCEL

GENERAL		USERS	OUTPUTS	INPUTS
M				JOB VERIFY BIT
N				RESET RESULT STATUS
P				REVERSE START
				DISABLE TOOL

OK CANCEL



GENERAL		USERS	OUTPUTS	INPUTS
N				IGNORE
P				IGNORE
R				IGNORE

EXIT CONFIG



GENERAL		USERS	OUTPUTS	INPUTS
N				IGNORE
P				START
R				SELECT JOB
				SELECT TASK

OK CANCEL

GENERAL		USERS	OUTPUTS	INPUTS
N				STOP
P				RESET JOB
R				TASK SELECT BIT
				JOB SELECT BIT

OK CANCEL

GENERAL		USERS	OUTPUTS	INPUTS
N				REVERSE
P				DISABLE TASK
R				DISABLE JOB
				TASK VERIFY

OK CANCEL

GENERAL		USERS	OUTPUTS	INPUTS
N				JOB VERIFY
P				TASK VERIFY BIT
R				JOB VERIFY BIT
				RESET RESULT STATUS

OK CANCEL

GENERAL		USERS	OUTPUTS	INPUTS
N				JOB VERIFY BIT
P				RESET RESULT STATUS
R				REVERSE START
				DISABLE TOOL

OK CANCEL

Alpha Controller

Other Screens




INPUTS	MFB	TONES	TOOL
P		IGNORE	
R		IGNORE	
S		IGNORE	

EXIT CONFIG

Options Screen




GENERAL	USERS	OUTPUTS	INPUTS
P		IGNORE	
R		START	
S		SELECT JOB	
		SELECT TASK	

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
P		STOP	
R		RESET JOB	
S		TASK SELECT BIT	
		JOB SELECT BIT	

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
P		REVERSE	
R		DISABLE TASK	
S		DISABLE JOB	
		TASK VERIFY	

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
P		JOB VERIFY	
R		TASK VERIFY BIT	
S		JOB VERIFY BIT	
		RESET RESULT STATUS	

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
P		JOB VERIFY BIT	
R		RESET RESULT STATUS	
S		REVERSE START	
		DISABLE TOOL	

OK CANCEL




INPUTS	MFB	TONES	TOOL
R		IGNORE	
S		IGNORE	
T		IGNORE	

EXIT CONFIG




GENERAL	USERS	OUTPUTS	INPUTS
R		IGNORE	
S		START	
T		SELECT JOB	
		SELECT TASK	

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
R		STOP	
S		RESET JOB	
T		TASK SELECT BIT	
		JOB SELECT BIT	

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
R		REVERSE	
S		DISABLE TASK	
T		DISABLE JOB	
		TASK VERIFY	

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
R		JOB VERIFY	
S		TASK VERIFY BIT	
T		JOB VERIFY BIT	
		RESET RESULT STATUS	


OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
R		JOB VERIFY BIT	
S		RESET RESULT STATUS	
T		REVERSE START	
		DISABLE TOOL	

OK CANCEL

Other Screens

Options Screen



GENERAL	USERS	OUTPUTS	INPUTS
S	IGNORE		
T	IGNORE		
U	IGNORE		

EXIT CONFIG



GENERAL	USERS	OUTPUTS	INPUTS
S	IGNORE		
T	START		
U	SELECT JOB		
	SELECT TASK		

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
S	STOP		
T	RESET JOB		
U	TASK SELECT BIT		
	JOB SELECT BIT		

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
S	REVERSE		
T	DISABLE TASK		
U	DISABLE JOB		
	TASK VERIFY		

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
S	JOB VERIFY		
T	TASK VERIFY BIT		
U	JOB VERIFY BIT		
	RESET RESULT STATUS		

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
S	JOB VERIFY BIT		
T	RESET RESULT STATUS		
U	REVERSE START		
	DISABLE TOOL		

OK CANCEL



GENERAL	USERS	OUTPUTS	INPUTS
S	IGNORE		
T	IGNORE		
U	IGNORE		

EXIT CONFIG



GENERAL	USERS	OUTPUTS	INPUTS
S	IGNORE		
T	START		
U	SELECT JOB		
	SELECT TASK		

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
S	STOP		
T	RESET JOB		
U	TASK SELECT BIT		
	JOB SELECT BIT		

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
S	REVERSE		
T	DISABLE TASK		
U	DISABLE JOB		
	TASK VERIFY		

OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
S	JOB VERIFY		
T	TASK VERIFY BIT		
U	JOB VERIFY BIT		
	RESET RESULT STATUS		


OK CANCEL

GENERAL	USERS	OUTPUTS	INPUTS
S	JOB VERIFY BIT		
T	RESET RESULT STATUS		
U	REVERSE START		
	DISABLE TOOL		

OK CANCEL

Alpha Controller

Other Screens



GENERAL

USERS

OUTPUTS

INPUTS

S	IGNORE
T	IGNORE
U	IGNORE

EXIT

CONFIG



USERS

OUTPUTS

INPUTS

TRIGGERS

Multi-Function Button

Tap Action	REVERSE
Hold Action	DISABLED

EXIT



USERS

OUTPUTS

INPUTS

TRIGGERS

Hold Action	DISABLED
-------------	----------

Lever / Push-To-Start Switch

Start Input	ANY
-------------	-----

EXIT

Options Screen



GENERAL

USERS

OUTPUTS

INPUTS

S	IGNORE
T	START
U	SELECT JOB
	SELECT TASK

OK

CANCEL



GENERAL

USERS

OUTPUTS

INPUTS

S	STOP
T	RESET JOB
U	TASK SELECT BIT
	JOB SELECT BIT

OK

CANCEL



GENERAL

USERS

OUTPUTS

INPUTS

S	REVERSE
T	DISABLE TASK
U	DISABLE JOB
	TASK VERIFY

OK

CANCEL



GENERAL

USERS


OUTPUTS

INPUTS

S	JOB VERIFY
T	TASK VERIFY BIT
U	JOB VERIFY BIT
	RESET RESULT STATUS

OK

CANCEL



GENERAL

USERS

OUTPUTS

INPUTS

S	JOB VERIFY BIT
T	RESET RESULT STATUS
U	REVERSE START
	DISABLE TOOL

OK

CANCEL



USERS

OUTPUTS

INPUTS

TRIGGERS

Multi-Function But

Tap Action	DISABLED
Hold Action	REVERSE
	TASK SELECT
	ARM

OK

CANCEL



USERS

OUTPUTS

INPUTS

TRIGGERS

Multi-Function But

Tap Action	ARM
Hold Action	RESET REJECT
	JOB SELECT
	JOB RESET

OK

CANCEL



USERS

OUTPUTS

INPUTS

TRIGGERS

Hold Action	DISABLED
-------------	----------

Lever / Push-To-St

Start Input	REVERSE
	TASK SELECT
	ARM

OK

CANCEL



USERS

OUTPUTS

INPUTS

TRIGGERS






















Hold Action	ARM
-------------	-----

Lever / Push-To-St

Start Input	RESET REJECT
	JOB SELECT
	JOB RESET

OK

CANCEL




Other Screens	Options Screen
 	  
 	 
 	
 	   
 	 

Alpha Controller



Other Screens	Options Screen
	<div data-bbox="873 205 1360 342"> <div> <div>IMPUTS</div> <div>TRIGGERS</div> <div>LIGHTS</div> <div>TONES</div> </div> <div> <div>Accept Tone</div> <div>Reject Tone</div> </div> <div> <div>FIFTH</div> <div>FURELISE</div> <div>TURKISHMARCH</div> <div>FUNERALMARCH</div> </div> <div> <div>OK</div> <div>CANCEL</div> </div> </div> <div data-bbox="873 352 1360 489"> <div> <div>IMPUTS</div> <div>TRIGGERS</div> <div>LIGHTS</div> <div>TONES</div> </div> <div> <div>Accept Tone</div> <div>Reject Tone</div> </div> <div> <div>FUNERALMARCH</div> <div>NINTH</div> <div>MICHIGAN</div> <div>OHIO</div> </div> <div> <div>OK</div> <div>CANCEL</div> </div> </div>
<div data-bbox="349 499 620 636"> <div>123</div> <div>456</div> <div>789</div> <div>0</div> </div> <div data-bbox="349 646 836 783"> <div> <div>TRIGGERS</div> <div>LIGHTS</div> <div>TONES</div> <div>TOOL</div> </div> <div> <div>PM Limit</div> <div>Temperature Limit</div> <div>Torsion Factor</div> </div> <div> <div>45000</div> <div>85</div> <div>0</div> </div> <div> <div>EXIT</div> </div> </div>	
<div data-bbox="349 793 620 930"> <div>123</div> <div>456</div> <div>789</div> <div>0</div> </div> <div data-bbox="349 940 836 1077"> <div> <div>TRIGGERS</div> <div>LIGHTS</div> <div>TONES</div> <div>TOOL</div> </div> <div> <div>Temperature Limit</div> <div>Torsion Factor</div> <div>Requires Arming</div> </div> <div> <div>85</div> <div>0</div> <div>NO</div> </div> <div> <div>EXIT</div> </div> </div>	
<div data-bbox="349 1087 620 1224"> <div>123</div> <div>456</div> <div>789</div> <div>0</div> </div> <div data-bbox="349 1234 836 1371"> <div> <div>TRIGGERS</div> <div>LIGHTS</div> <div>TONES</div> <div>TOOL</div> </div> <div> <div>Temperature Limit</div> <div>Torsion Factor</div> <div>Requires Arming</div> </div> <div> <div>85</div> <div>0</div> <div>NO</div> </div> <div> <div>EXIT</div> </div> </div>	
<div data-bbox="349 1381 511 1465"> <div>123</div> <div>456</div> <div>789</div> <div>0</div> </div> <div data-bbox="349 1476 836 1612"> <div> <div>TRIGGERS</div> <div>LIGHTS</div> <div>TONES</div> <div>TOOL</div> </div> <div> <div>Temperature Limit</div> <div>Torsion Factor</div> <div>Requires Arming</div> </div> <div> <div>85</div> <div>0</div> <div>NO</div> </div> <div> <div>EXIT</div> </div> </div>	<div data-bbox="873 1381 1036 1465"> <div>123</div> <div>456</div> <div>789</div> <div>0</div> </div> <div data-bbox="873 1476 1360 1612"> <div> <div>TRIGGERS</div> <div>LIGHTS</div> <div>TONES</div> <div>TOOL</div> </div> <div> <div>Temperature Limit</div> <div>Torsion Factor</div> <div>Requires Arming</div> </div> <div> <div>85</div> <div>0</div> <div>NO</div> <div>YES</div> </div> <div> <div>OK</div> <div>CANCEL</div> </div> </div>
<div data-bbox="349 1633 620 1770"> <div>123</div> <div>456</div> <div>789</div> <div>0</div> </div> <div data-bbox="349 1780 836 1917"> <div> <div>75</div> <div>LIGHTS</div> <div>TONES</div> <div>TOOL</div> <div>STATS</div> </div> <div> <div>Population</div> <div>Subgroup Size</div> </div> <div> <div>25</div> <div>5</div> </div> <div> <div>EXIT</div> </div> </div>	

Other Screens







Options Screen





Alpha Controller

Other Screens	Options Screen
 <p>The screen displays 'Time' as 21:20:35 and 'Date' as 6/11/2008. An 'EXIT' button is at the bottom.</p>	
 <p>The screen shows a confirmation dialog: 'Save changes?' with 'YES', 'NO', and 'CANCEL' buttons.</p>	

2.5.4 Setup Menu: 4. Full Backup/Restore






Full Backup/Restore Screens	Options Screen
 <p>The screen shows the 'SETUP' menu with options: 1. Jobs, 2. Communications, 3. Other, 4. Full Backup/Restore. 'OK' and 'CANCEL' buttons are at the bottom.</p>	
 <p>The screen shows the 'BACKUP/RESTORE' menu with 'Up One Level' selected. Buttons at the bottom: EXIT, BACKUP, RESTORE, DEFAULTS.</p>	 <p>The screen shows the 'BACKUP' screen with 'File Name' set to 'backup'. Buttons: SAVE, CANCEL.</p>
	 <p>The screen shows 'Complete!' with an 'OK' button.</p>
	 <p>The screen shows the 'RESTORE' screen with 'Are you sure?' confirmation. Buttons: YES, NO.</p>
	 <p>The screen shows 'Complete!' with an 'OK' button.</p>

To select a file, use the up and down arrow










Full Backup/Restore Screens	Options Screen
	<p>keys to scroll through list. To change directories, highlight “Up One Level” and then press the center button.</p> <p>DEFAULTS</p>   <p>The default button loads current software factory defaults.</p>

2.5.5 Service



2.5.5.1 Tool



Tool Tab Screens	Options Screen
<p>The odometer increments after every in cycle.</p> 	
 	
	

Alpha Controller





Tool Tab Screens	Options Screen
	   
 	
 	

2.5.5.2 Controller


Controller Tab Screens	Options Screen
The odometer increments after every in cycle.	
	

Controller Tab Screens	Options Screen
 <p>The Controller Tab Screens consist of two screens. The first screen shows 'Controller' information with fields for Model and Serial, and an EXIT button. The second screen shows 'Serial', 'Software Version', and 'Servo Version' information, also with an EXIT button.</p>	
 <p>This screen shows 'Up One Level...' with an arrow pointing left, and EXIT and UPDATE buttons.</p>	










2.5.6 Analyze



Diag Screens	Options Screen
Analyze displays tool and controller diagnostic information, statistics, traces and I/O status.	
 <p>The Analyze Tool Screen shows various diagnostic data including TORQUE, °C, DEG, RPM, and various voltage and frequency readings. It includes EXIT and STATS buttons.</p>	
 <p>The Analyze Trace Screen is a large empty area for displaying traces, with EXIT and STATS buttons at the bottom.</p>	
 <p>The Analyze I/O Screen shows Inputs and Outputs status with various control buttons like ON, OFF, and REMOVE.</p>	 <p>When forcing I/O changes during an operation, the system provides a warning first. The warning screen displays 'WARNING! Forcing may interrupt operation. Continue?' with YES and NO buttons.</p>

Clear = off, Dark = on

Diag Screens – STATS Button	Options Screen
 <p>A button labeled 'STATS'.</p>	

Alpha Controller

Diag Screens – STATS Button	Options Screen
	
	
	
	
	   

Diag Screens – STATS Button	Options Screen
	

QPM DC Electric Tools

This chapter is intended to promote proper and safe use and give guidance to owners, employers, supervisors and others responsible for training and safe use by operators. DC Electric tools from STANLEY ASSEMBLY TECHNOLOGIES are intended for use in industrial threaded fastening or precision position and or adjustment applications only. Some instructions may not apply to all tools. Please contact your Stanley Sales Engineer for information or assistance on Stanley training for assembly tool operation.

3.1 Tool Specifications

Operating Conditions	Temperature	32 to 122 °F (0 to +50 °C)
	Humidity	0 to 95 % non-condensing

STANLEY ASSEMBLY TECHNOLOGIES hereby declares the following sound and vibration emission levels as required by the Machinery Directive 98/37/EC.

Product	A-weighted emission sound pressure level at the work station L_{pA} (ref 20 μ Pa). Value determined according to ISO 15744-2002 * using as basic standards ISO 3744 and ISO 11203	Weighted emission root mean square acceleration level at the handle. Value determined according to ISO 8662 * (single axis)
E0, E1, E2, EA2, E3, EA3, E4 and E5 electric tools	< 70dBA	< 2.5 m/s ²

* Operating conditions for all measurements: full rated speed, no load, rated supply voltage or pressure.

A-weighted emission sound power level L_{WA} : not required, declared sound pressure emission levels are below 85dBA.

C-weighted peak emission sound pressure level L_{pCpeak} : not applicable to these products.

Uncertainty K_{pA} , K_{WA} , K_{pCpeak} : not relevant, declared levels are maximum values.



WARNING

To Avoid Injury:

This information is provided to assist in making rough estimates of sound and vibration exposure levels in the workplace. The declared emission values were obtained by laboratory type testing in accordance with the stated standards. **Levels measured in individual workplaces may be higher.**

The actual exposure levels and risk of harm experienced by an individual user depends upon the work piece, workstation design, duration of exposure, and the physical condition and work habits of the user. To help prevent physical impairment, a program of health surveillance is highly recommended to detect early symptoms which may relate to sound and/or vibration exposure, such that appropriate preventive measures may be taken.

3.2 Operator Protection



WARNING

ROTATING EQUIPMENT

To Avoid Injury:

- Always wear eye and foot protection when operating, installing, or maintaining power tools, and when in areas where power tools are being used, maintained, or installed. Some applications may require the use of safety glasses and face shields. Use eye protection that conforms to ANSI Z87.1.[3] and ANSI Z41-PT99M I/75 C/75.
- Always stay alert when operating tools and/or their accessories. Do not operate tools and/or their accessories while tired, under the influence of drugs, alcohol or any other mind-altering substance.
- Repetitive work motions or vibration may be harmful to your hands, arms, shoulders or back.
- Use suitable protective equipment and work methods whenever an application presents a hazard.

Repetitive Motion

The use of power tools may involve highly repetitive motions of the fingers, hands, wrists, and shoulders. These repetitive motions can lead to cumulative trauma disorders (CTD). Many personal and workplace factors can contribute to these disorders.

Currently available data have identified the following risk factors. These risk factors are not necessarily causation factors of CTDs. The mere presence of a risk factor does not necessarily mean there is excessive risk of injury. Generally, the greater the exposure to a single risk factor or combination of factors the greater the risk for CTDs.

- Forceful exertions and motions
- Extreme postures and motions
- Repetitive exertions and motions
- Intended duration of exertion, postures, motions, vibration, and cold
- Insufficient rest or pauses
- Work organization risk factors
- Environmental risk factors

These risk factors span job design and content, operator training, work method, work pace, work environment, proper tool selection and other work place factors beyond the control of the tool manufacturer. Tool owners and employers should analyze jobs for all of the risk factors identified above and take appropriate action.

Some measures which may reduce the risk of CTDs:

- Use minimum hand grip force consistent with proper control and safe operation.
- Keep wrists as straight as possible.
- Avoid repetitive movements of the hands and wrists.
- If wrist pain, hand tingling, numbness, or other disorders of the shoulders, arm, wrist or finger occur; notify supervisor, discontinue task, reassign user to a different job; if relief is not found contact experts skilled in treating such disorders.

Wrist supports, torque reaction devices, and balancers should be used if it can be determined that such devices can reduce the risk of repetitive motion disorders.

3.2.1 Hearing Protection

Power tool operators and adjacent personnel may be exposed to excessive sound levels. The tool in use is generally only one of many sources of noise that an operator experiences. Other tools and machines in the area, joint assembly noise, work processes, and other ambient noise sources all contribute to the sound level operators are exposed to.

The actual sound level an individual is exposed to and the individual's exposure time over the work day are important factors in determining hearing protection requirements. Worker sound level exposure can only be determined at the job site and is the responsibility of tool owners and employers.

Alpha Controller

Measure worker sound level exposure and identify high-risk noise areas where hearing protection is required.

Follow federal (OSHA), state or local sound level statutes, ordinances and or regulations.

3.2.2 Vibration

Power tools can vibrate during use. To minimize the possible effects of vibration:

- Keep hands and body dry.
- Avoid anything that inhibits blood circulation such as tobacco, cold temperatures and certain drugs.
- Operators should notify their employer when experiencing prolonged symptoms of pain, tingling, numbness or blanching of the fingers.
- Wear vibration damping gloves if it can be determined that they reduce the risk of vibration disorders without introducing other hazards.

3.2.3 Breathing Protection

Respirators shall be used where contaminants in the work area present a hazard.

3.3 Tool Installation



WARNING

To Avoid Injury:

- Always wear eye and foot protection when installing equipment.
- Only use equipment and accessories specifically designed to operate with Stanley assembly tools and use them only in the manner for which they are intended.
- Do not install worn, damaged, or modified equipment that may be unsuitable for safe use.
- Train all operators in the safe and proper use of power tools. Operators should report any unsafe condition.
- Store idle tools and accessories in a safe location accessible only by trained persons.
- Disconnect power source (air, electricity, etc.) from tool prior to making adjustments, changing accessories, or storing.
- Prior to operation, always check and test tools and accessories for damage, misalignment, binding or any other condition that may affect operation. Maintenance and repair should be performed by qualified personnel.
- Do not operate tools in or near explosive environments or in the presence of flammable liquids, gases, dust, rain or other wet conditions.
- Keep the work area clean, well lit and uncluttered.
- Keep unauthorized personnel out of the work area.

DC Electric Tools & Controllers:

- Install tools in dry, indoor, non-flammable, and non-explosive environments only – Humidity: 0 to 95% non-condensing and Temperature: 32 to 122 °F (0 to +50 °C).
- Installation, maintenance and programming should be performed by qualified personnel. Follow all manufacturer installation instructions and applicable regulatory electrical codes and safety codes.
- Tool and controller plugs must match the outlet. This equipment must be earth grounded. Never modify a plug in any way or use any adaptor plugs.
- Avoid body contact with electrically energized surfaces when holding a grounded tool.
- Prior to connecting a power source, always ensure the tool or controller is turned off.
- Limit controller access to trained and qualified personnel. Lock controller cabinets.

Turn controllers off when attaching tools.

Stanley electric tools must be connected to a controller to operate. To ensure superior performance and safe operation, use a Stanley controller specifically designed for each tool. These instructions are specific to Stanley Electric Tools when used with Stanley Electric Tool Controllers and accessories. Some features may not be applicable, performance may be degraded and some safety systems may not be available when tools are connected to non-Stanley controllers and accessories.

3.3.1 Sockets and Adapters

Use only industrial grade sockets and adapters (power bit and power or impact socket type).

Replace worn or damaged sockets that are unsuitable for safe operation immediately.

Always ensure drive socket is fully seated and locked into position before connecting power to tool.

3.3.2 Suspension Devices

Tool suspension devices or bails help support the weight of the tool during tightening operations. Attach these devices securely and periodically inspect them for damage or loosening.

3.3.3 Cable Installation



WARNING

ELECTRICAL HAZARD

To Avoid Injury:

- Never use a tool with a damaged cable.
- Never abuse a cable, carry a tool by its cable, hang a tool by its cable, or pull on a cable to disconnect it from the tool or the controller.

To ensure superior performance and safe operation, use the Stanley cables specifically designed to operate these tools.


Never use a tool with a damaged cable. Never abuse a cable, carry a tool by its cable or pull a cable to disconnect it. Also, keep the cord away from heat, sharp edges, or moving parts.

Use cables of appropriate length (60M maximum) for each application; position and or suspend them in such a way as to prevent tripping and cable damage, and to provide good work area maneuverability.


3.4 QPM Tools

3.4.1 Display and Multiple Function Button for Hand Held Tools


Handheld QPM tools have a display and a multiple function button. Two sets of lights [3 and 7] indicate rundown status. Two blue lights indicate tool rotation direction, disassembly [1] or assembly [2]. A single multiple function button [5] is programmable to perform different functions when it is either tapped or held for 2 seconds. A short list of functions that are programmable include changing tool direction, selecting tasks or jobs, or arming for tubenut operation. See section 3.4.2 for a complete list. When the button is used to select the task, or job, one of two orange indicators [4 or 6] illuminates to show the active task, or job. EA tools have four sets of lights [3 and 7] and an LED [8] that indicates when the Preventive Maintenance (PM) count exceeds the PM limit.



Display and MFP Button
for E02P to E34P (pistol) Models



Display and MFP Button
for E23L to E55L (lever) Models



Display for EA23L to EA34L (lever) Models

Alpha Controller

3.4.2 MFP Mode

The *MFP Mode* configures the multiple function button for handheld QPM tools. The button can be configured to operate in any of the following modes with either a tap or a 2-second hold. You may program one function for tap and a second function for hold.

Disable (default)	The button does nothing. Pressing the button causes the tool alarm to "beep" once. Only the assembly blue light [2] illuminates.
Reverse (Disassembly)	Pressing the button toggles between assembly and disassembly and illuminates the appropriate blue light [1] or [2]. All tool status lights [3] and [7] flash when the tool is in disassembly mode.
Job or Task Select	Pressing the button toggles between job 1 and job 2, or task 1 and task 2, and illuminates the appropriate orange light [6] or [4].
Arm	Pressing the button arms (activates) the start function but does not start the tool. The tool is allowed to start once the button is pressed. This arming is active for 5 seconds. If the tool is not run within 5 seconds, it will disarm automatically. The blue assembly light [2] comes on to show that the tool is armed and will go off when the tool is disarmed.
Reset Reject	When Reset Reject is selected and the rundown status is NOK, (red or yellow light illuminated) the tool becomes disabled and the reject tone will continue to sound until the MFP is pressed. Pressing the button stops the reject tone and re-enables the tool.
Job Reset	Pressing the button will reset the accumulated bolt count back to zero for the active job and act as a Part Entry to re-enable the tool if disabled.

3.4.3 Tool Memory

QPM tools have an onboard tool memory that stores tool identification, calibration factors and tightening cycle counters. Memory parameters include:

- *Model Number*
- *Serial Number*
- *Torque Cal* (calibration) factor
- *Angle Cal* (calibration) factor
- Tightening cycle counters

3.4.4 Tightening Cycle Counters

QPM tools have onboard counters that record the number of tightening cycles completed by the tool.

- *Odometer*. Records the total number of tightening cycle completed.
- *Trip Counter*. Records the number of tightening cycles completed since the last reset.
- *PM Counter*. Records the number of tightening cycles completed since the last reset.
- *PM Threshold*. When the PM Counter exceeds the PM Threshold (Limit), the controller provides a maintenance alert.

Each time the controller is turned on it reads the tightening cycle counters from the Tool Memory Board.

3.5 Tool Operation



WARNING

ROTATING SPINDLE

To Avoid Injury:

- Always wear eye and foot protection when operating and when in areas where power tools are being used.
- Keep all body parts and clothing away from the rotating end of the tool. Dress properly. Do not wear loose-fitted clothing or jewelry.

TORQUE REACTION FORCE

To Avoid Injury:

- Be alert and maintain good balance, footing, and posture at all times in anticipation of the tool's torque reaction. Do not over-extend or over-reach.
- Be prepared for the change in direction and or a higher reaction force when a tool is in reverse.
- The start lever should be positioned to avoid trapping the operator's hand between the tool and the work piece.

TOOL MAY NOT SHUT OFF

To Avoid Injury:

- If the tool does not shut off at the end of the tightening cycle, contact the person responsible for tool installation or repair. Note: When the tool does not shut off, a stall condition occurs. A stall condition can cause a higher than expected torque reaction impulse.
- Ensure tool is properly installed, adjusted and in good working order.
- Do not use the power tool if the switch does not turn it on and off.
- Apply the tool to the joint following all recommendations in this manual.
- Check to ensure the drive socket is fully seated and locked into position before connecting power to the tool.

Prepare to resist the tool's torque reaction:

Start the tool by depressing the start lever or trigger.

Release start lever after the cycle is complete.

3.5.1 Directional Control



WARNING

UNEXPECTED REACTION FORCES

To Avoid Injury:

- Be prepared – when a tool operates in reverse, the tool's torque reaction is opposite to the reaction produced when the tool operates in forward direction.
- The tool can have a higher initial reaction force when loosening a fastener.
- Always stop the tool before changing direction of spindle rotation.

3.5.2 Torque Reaction Devices



WARNING

PINCH POINT BETWEEN TORQUE REACTION BAR AND WORK PIECE

To Avoid Injury:

- Never place any body part between a reaction bar and the work piece.
- Before starting the tool, position the reaction bar firmly against a stationary rigid member that is opposite to the spindle rotation.

Torque reaction devices absorb tool torque reaction forces. Always use reaction devices when high reaction force could injure an operator.

Some reaction devices may require modification to fit the application. Follow all appropriate installation instructions.

Alpha Controller

3.5.3 Tool Temperature



WARNING

POTENTIAL BURN HAZARD

Fixtured tools have higher operating temperatures and do not have additional thermal protection.

To Avoid Injury:

Wear thermal protective gloves when handling fixtured tools.

Stanley electric tools are thermally protected to prevent overheating. The thermal protection does not allow the tool to operate if the tool temperature rises abnormally – the thermal protector automatically resets when the tool cools down.

Controller task settings can have a significant effect on tool operating temperatures.

3.5.4 Tool Status Lights

Handheld tools from STANLEY ASSEMBLY TECHNOLOGIES have three (green, yellow, and red) status lights. The status light mirror or copy the status lights on the controller or control panel.

Green	Tightened to specified limits	The tightening cycle meets all of the specified parameters.
Yellow	Low torque or angle	The tightening cycle was rejected for not reaching either low torque or low angle.
Red	High torque or angle	The tightening cycle was rejected for exceeding either high torque or high angle.
All lights	Reverse	The next time the start trigger is engaged the tool will release the fastener.

3.5.5 Setting Torque, Angle, and Other Operating Parameters



WARNING

EXCESSIVE TORQUE CONDITION

To Avoid Injury:

- Only trained and qualified personnel should program controllers.
- Never set control limits above the maximum rating of the tool.
- Setting control limits above the maximum rating of the tool can cause high reaction torque.
- Always test for proper tool operation after programming the controller.

The Alpha controller can be setup to change tightening parameters from the tool.

3.6 Special Application Tools

3.6.1 Exposed Gear Socket Tools



WARNING

PINCH POINT AT THE EXPOSED GEARS OR TEETH

To Avoid Injury:

Keep body parts and clothing away from the exposed gear sockets. Dress properly. Do not wear loose-fitted clothing or jewelry.

Exposed gear socket tools are designed to fit into tight spaces where other tools do not fit. These tools have exposed gears or ratchet teeth.

3.6.2 Tubenut Nutrunners



WARNING

PINCH POINT AT THE EXPOSED GEARS OR TEETH

To Avoid Injury:

- Never place body parts or clothing, near the socket opening. Dress properly. Do not wear loose-fitted clothing or jewelry.
- Follow the Tubenut Nutrunner Sequence of Operation

Tubenut nutrunners are used for installing tube fittings.

Tubenut Sequence of Operation (QPM Tools)

- Place nutrunner socket on fastener
- Press the button on the multiple function panel to “arm” the start function (not required in modes 0 and 2)
- Depress start lever
- The tool stops after reaching torque
- Release the lever and lift the tool from the fastener, all tool status lights flash to indicate the tool will now run in reverse to open the socket
- Depress the start lever until the socket returns to the open position
- Release the lever
- Remove the tool

Controller Connections and Inputs/Outputs

Each Alpha Controller can have a different combination of connectors. These connectors serve several purposes, such as:

- Power
- Tool Connections
- Discrete inputs and outputs



CAUTION

POTENTIAL ELECTROSTATIC DISCHARGE HAZARD AND WATER AND DIRT INGESTION To Avoid Damage:

If not using a connector, keep the connector securely covered with the provided cap. This reduces the opportunity for transfer of static electricity and prevents dirt and water from entering the controller.


4.1 Alpha Controller Connections

4.1.1 Alpha Controller Power Cord

Alpha Controllers use an IEC 60320 style connector. The power source connector for the power cord is based on customer requirements. The power cord should be rated at either 15A/125V for 115 V or 10A/250V for 230 V use of the controller.

4.1.2 Alpha Controller Tool Connector

Alpha controllers use a single 30 pin connector to connect two types of QPM DC electric tool cables (patent pending). QPM E__ DC electric tool cables use a MIL-C-38999 Series III connector. The connector is a 17-30S with the insert clocked in the normal position (30-pin Tool Connector). QPM EA DC electric tools use a similar connector except for B clocking.




30-pin Tool Connector

4.1.3 Alpha Controller Serial Connector

Alpha Controllers have two male DB-9 connectors. The setup is 9600-baud rate, 8 data bits, No Parity and 1 Stop bit, and is not programmable. The connection between the computer and the controller is a simple null-modem cable.

The one that is labeled COM PORT 1 has the intended purpose of connecting a laptop computer for access to Embedded Toolbox software. Other communication functions can be selected for the serial port besides Embedded Toolbox. Those choices are Barcode/Printer, Barcode or Printer.



DB-9 Connector Pins

Pin	Function	Pin	Function	Pin	Function
1	Carrier Detect	4	Data Terminal Ready	7	Request to Send
2	Receive Data	5	Signal Ground	8	Clear to Send
3	Transmit Data	6	Data Set Ready	9	Ring Indicator

A second DB-9 connector COM PORT 2 is available if needed. It also has options for different communication functions. The list includes:

- Barcode/Printer – This will read a barcode scanner and print the rundowns after they occur; see string below.
- Barcode – this will only read a read code scanner
- Printer – this will only print after a rundown occurs; see string below.
- PFCS – use this to connect to a Chrysler PFS system
- Toyota – use this to connect to a Toyota PI box
- Open – use this to connect to an Open protocol serial network.

Version 3.1


S01	JB01	4.1	A	126.2	A	A	06/09/2008	10:20:19		
										barcode
									second	
									minute	
								hour		
							year			
						day				
						month				
							overall status (A=OK, R=NOK)			
							angle status (A=OK, H=HIGH, L=LOW)			
							angle result (last step ran or audit step whichever is smaller, fixed decimals)			
							torque status (A=OK, H=HIGH, L=LOW)			
							torque result (last step ran or audit step whichever is smaller, decimals are tool/units dependant)			
						job number				
						spindle number (1=MASTER, 2=SLAVE)				

The above format has the following issues:

- Spindle number is not programmable.
- Task number is not present.
- Torque/angle results and status are not always from the audit step.
- There is no distinction between no angle and 0.0 degrees.

Alpha Controller

Version 3.0




The barcode input monitors inter character timing. When there is a 500ms gap between characters, a complete barcode is assumed. When received, the controller logs it with all rundowns until another barcode is received or until controller power is cycled. If the incoming barcode is longer than 32 characters then the last 32 characters received is used.

4.1.4 Alpha Controller Ethernet Connector

Alpha Controllers have a single RJ-45 Ethernet connection located on the bottom of the module for connecting to an Ethernet network. This network can consist of the controller and a PC all the way up to a plant-wide fastening network.

4.1.5 Alpha Controller (Model QA1001 _D_) DeviceNet™

Alpha Controllers can have a single Mini DeviceNet™ port for connecting the Alpha Controller to a master controller such as a PLC.



4.1.6 Alpha Controller (Model QA1001 _P_) Profibus Port

Alpha Controllers can have a single Profibus port for connecting the Alpha Controller to a master Profibus controller from another manufacturer.




Figure 4-1 DB-9 Connector Pins (Profibus Port)

Pin	Function	Pin	Function	Pin	Function
1	Empty	4	Repeater	7	Blank
2	Empty	5	Data Ref	8	Data Line Inverse
3	Data Line	6	Power Supply	9	Empty


4.1.7 Alpha Controller (Model QA1001 __V) Input and Output Connector

All 24 VDC inputs and outputs are optically isolated

- Internal 24 VDC supply: Maximum = 1 ampere total
- External 24 VDC supply: Maximum = 1 ampere per output

The Alpha controller has a MIL-C-26482 Series II bayonet connector for 24VDC I/O. The connector uses a 12-8S insert in the normal position. Connector options are listed below.

Part No.	19-pin 24V I/O Port	Included
21C104800	Mating Connector - Solder pins	Standard
21C104802	Mating Connector - Crimp pins	Optional
21C104804	Mating Connector - Crimp pins, crimp tool	Optional
21E102202	Breakout Box for plinth mounting	Optional
21C202005	Extension Cable 5M	Optional
21C202010	Extension Cable 10M	Optional
21C202020	Extension Cable 20M	Optional



When the Alpha controller is used with fixtured tools, it must use a Remote Start/Stop/Reverse pendant to the controller to provide basic switching control for the tool.

4.2 Assignable Input/Output Functions

The following Input/Output (I/O) functions apply to DeviceNET, Profibus, Modbus/TCP, EthernetIP and 24V. There is a maximum of eight inputs and eight outputs for the 24 VDC I/O connector. There is a maximum of 512 bytes of input and 512 bytes of output on each Fieldbus used with the controller with the exception of DeviceNet which is limited to 256 bytes of both inputs and outputs. Ninety-nine is the maximum number of I/O functions that can be assigned to each type of input or output. Each I/O function can have a length of one bit all the way up to 32 bits. You must keep track of the lengths for each I/O function you assign to stay within the maximum length of the type of I/O you are using.

More than one type of I/O connection can be used at the same time. For instance, the controller can use the 24 VDC I/O connector AND Modbus/TCP on Ethernet AND DeviceNet all at the same time. If more than one type of Input uses a particular input function, the controller will respond to an input when it is asserted or removed, not while it is being held on or off. It is important to understand the controller responds to the rising and falling edges of input functions as they are asserted or removed, not while the levels are high or low. The STOP bit is an exception: it is a true "OR" function rather than working off the transition. One type of Input does not have priority over the other. The controller will respond to the first *change* in status of an input function, no matter which Input connection makes the change.

If more than one type of Output shares a particular output function, that function is asserted on all types of Output.

The table below lists the available input and output functions, gives a brief description and indicates the configuration options for each. The configuration options are an important aspect of the I/O functions, as they add powerful, multiple dimensions to each function not previously seen in Stanley tool controllers. These new dimensions allow integration of these controllers in unique ways, providing an amazing amount of flexibility.

Please see the full description of each function in the section following this table.

See Appendix A for assigning of inputs and outputs using Embedded Tool Box.

Inputs	Description	Configuration Options
IGNORE	Input is ignored	Input is not assigned

Alpha Controller

START	Start the tool	N.O./N.C., Latch, Timer
SELECT JOB	Select a job	N.O./N.C., Job, Disable when open
SELECT TASK	Select a task	N.O./N.C. , Task, Disable when open
STOP	Stop the tool	N.O./N.C.
RESET JOB	Reset a job	N.O./N.C.
TASK SELECT BIT	One bit in a series to select the task	N.O./N.C., Bit
JOB SELECT BIT	One bit in a series to select the job	N.O./N.C., Bit
REVERSE	Put the tool in reverse	N.O./N.C.
DISABLE TASK	Disable the task	N.O./N.C., Task
DISABLE JOB	Disable the job	N.O./N.C., Job
TASK VERIFY	Verify the selected task to the inputs	N.O./N.C., Task
JOB VERIFY	Verify the selected job to the inputs	N.O./N.C., Job
TASK VERIFY BIT	Verify the selected task to one of the input bits in a series	N.O./N.C., Bit
JOB VERIFY BIT	Verify the selected job to one of the input bits in a series	N.O./N.C., Bit
RESET RESULT STATUS	Clear the result status	N.O./N.C.
REVERSE START	Put the tool in reverse and start the tool	N.O./N.C.
DISABLE TOOL	Disable tool (will complete running if it is in cycle)	N.O./N.C.
*PART ID	Sets the part identification	Length, Trigger
*PART ID TRIGGER	Trigger for PART ID / Resets PART ID CHANGED output.	N.O./N.C.

* Input not available on 24V

Outputs	Description	Configuration Options
OFF	Output is turned off	Output is not assigned
IN CYCLE	The tool is in cycle	N.O./N.C., Type, Time
JOB SELECTED	Indicates a specific job is selected	N.O./N.C., Type, Time, Job
DISASSEMBLY DETECTED	A tightened fastener removed has been loosened	N.O./N.C., Type, Time
TOOL RUNNING	The tool is running	N.O./N.C., Type, Time
CYCLE OK	Rundown was OK	N.O./N.C., Type, Time
CYCLE NOK	Rundown was NOK	N.O./N.C., Type, Time
TASK SELECTED	Indicates a specific task is selected	N.O./N.C., Type, Time, Task
JOB COMPLETE	Job complete (all bolts in job are OK)	N.O./N.C., Type, Time, Job
TASK COMPLETE	Task complete (all bolts in task are OK)	N.O./N.C., Type, Time, Task
TASK SELECTED BIT	A bit to indicate the selected task in a series of bits	N.O./N.C., Bit, Mode

JOB SELECTED BIT	A bit to indicate the selected job in a series of bits	N.O./N.C., Bit, Mode
TORQUE OK	Rundown Torque was within limits	N.O./N.C., Type, Time, Step
TORQUE HIGH	Rundown Torque exceeded High limit	N.O./N.C., Type, Time, Step
TORQUE LOW	Rundown Torque under Low limit	N.O./N.C., Type, Time, Step
ANGLE OK	Rundown Angle was within limits	N.O./N.C., Type, Time, Step
ANGLE HIGH	Rundown Angle exceeded High limit	N.O./N.C., Type, Time, Step
ANGLE LOW	Rundown Angle under Low limit	N.O./N.C., Type, Time, Step
CYCLE ABORTED	The rundown was aborted / stopped	N.O./N.C., Type, Time
STOPPED	A STOP input is asserted	N.O./N.C., Type, Time
FAULTED	A fault condition is active	N.O./N.C., Type, Time
READY	The tool is ready to run	N.O./N.C., Type, Time
PM	The tool requires service	N.O./N.C., Type, Time
*TORQUE	Torque result value	Format, Step
*ANGLE	Angle result value	Format, Step
*FAULT CODE	Fault code value	Format
*PARAMETER	Parameter number	Format, Step
START TRIGGER	Shows the state of the tool trigger	N.O./N.C., Type, Time
MFB	Shows the state of the multifunction button	N.O./N.C., Type, Time
SNUG ACHIEVED	Is set when Snug torque exceeded	N.O./N.C., Type, Time
CYCLE STOP	Shut off code is STOP	N.O./N.C., Time
*PART ID CHANGED	Controller has read the PART ID	N.O./N.C., Type, Time
STEP BIT	Indicates last step of rundown in a series of bits	N.O./N.C., Bit, Mode

* Outputs not available on 24 VDC

4.2.1 Input Descriptions

Each of the single bit input functions has a Configuration setting of Contact Type. The Contact Type can be Normally Open (N.O.) or Normally Closed (N.O.). If an input's contact type is normally open, the input is asserted when 24 VDC is applied to the 24 VDC connector input pin, or when the fieldbus bit transitions from low to high. If an input's contact type is normally closed, the input is asserted when the 24 VDC is removed from the 24 VDC connector input pin, or when the fieldbus bit transitions from high to low.

Inputs	Description
IGNORE	The pin or bit that is assigned as IGNORE means the input will do nothing when asserted. This is essentially a placeholder. For fieldbus, the length of this input function may be set to any size that meets the need.
START	When asserted, on any input type, the tool will start and run the currently selected job / task. This input is overridden by the STOP input. If STOP is used and a tool restart is required, remove the STOP, remove the START, then re-assert the START. If the tool is required to operate in Disassembly mode, remove the START, assert the REVERSE input, and then re-assert the START. When removed, from any type of Input, the tool will stop. Even if a second START input is active, the tool will stop when any START is removed. The size of this input function is 1 bit. Configuration: Contact Type: Normally Open (N.O)

Alpha Controller

Inputs	Description
	<p>Normally Closed (N.C.)</p> <p>Latch: This is applicable to external inputs only. This is not applicable to the trigger on the tool handle.</p> <p>Yes – when selected causes the START input to latch internally after a time period has elapsed. This means the physical START input can be removed without stopping the tool. The tool will run until the currently active task is complete or times out. A TIME parameter becomes available to set how long the START input must be applied, in seconds, before the Latch becomes active.</p> <p>No – when selected turns the Latch function off.</p>
SELECT JOB	<p>When asserted, on any input type, the controller will make the job assigned specifically to this input the active job.</p> <p>When removed either nothing will happen or if “Disable when open” is selected as yes, then the tool will be disabled.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p>Contact Type:</p> <p>Normally Open (N.O.)</p> <p>Normally Closed (N.C.)</p> <p>Job: Type in the job number you wish to select when this input is asserted.</p> <p>Disable when open:</p> <p>Yes – Will disable the tool when this input is removed.</p> <p>No – Will not disable the tool upon input removal.</p>
SELECT TASK	<p>When asserted, on any input type, the controller will make the task assigned specifically to this input the active task.</p> <p>When removed either nothing will happen or if “Disable when open” is selected as yes, then the tool will be disabled.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p>Contact Type:</p> <p>Normally Open (N.O.)</p> <p>Normally Closed (N.C.)</p> <p>Task: Type in the job number you wish to select when this input is asserted.</p> <p>Disable when open:</p> <p>Yes – Will disable the tool when this input is removed.</p> <p>No – Will not disable the tool upon input removal.</p>
STOP	<p>When asserted, on any input type, the controller will stop the tool. It will also keep the tool from running while it is applied.</p> <p>When removed nothing will happen other than the tool will be allowed to run.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p>Contact Type:</p> <p>Normally Open (N.O.)</p> <p>Normally Closed (N.C.)</p>
RESET JOB	<p>When asserted, on any input, the controller will reset the accumulated bolt count back to zero for the active job and act as a Part Entry to re-enable the tool if disabled. The tool could be disabled due to “Error Proofing” having been enabled and the accumulated bolt count equal to target bolt count.</p> <p>When removed nothing will happen.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p>Contact Type:</p> <p>Normally Open (N.O.)</p>

Inputs	Description																								
	Normally Closed (N.C.)																								
TASK SELECT BIT	<p>When asserted or removed, on any input type, the controller will select a task. This is one bit, in a series of bits, to create a binary number.</p> <p>The number created by this and other TASK SELECT BIT inputs will determine which task will become the active task for the tool to run. You will need to have more than one input assigned as a TASK SELECT BIT in order to create a number greater than one. The maximum number of tasks required will determine the maximum number of inputs requiring this input function assignment.</p> <p>In binary numbers, the digit furthest to the right is the "ones" digit; the next digit to the left is the "twos" digit; next comes the "fours" digit, then the "eights" digit, and so on. The integer equivalent to a binary number can be found by summing all the weighted values of the selected digits. For example, the binary number 10101 is equivalent to the integer 21. The math is 1 + 4 + 16 = 21: where the digits that are high (one) are added together and the digits that are low (zero), are ignored.</p> <table><tr><td>Bit Number</td><td>4</td><td>3</td><td>2</td><td>1</td><td>0</td></tr><tr><td>Weighted Value</td><td>16</td><td>8</td><td>4</td><td>2</td><td>1</td></tr><tr><td>Binary Number</td><td>1</td><td>0</td><td>1</td><td>0</td><td>1</td></tr><tr><td>24 VDC Pins (example)</td><td>R</td><td>P</td><td>N</td><td>M</td><td>L</td></tr></table> <p>In order to select task #21 on the controller you would need at least 5 inputs assigned as TASK SELECT BIT. Each would then have to be given a bit number in order to have a series of bits with different weighted values. For example, on the 24 VDC input pin L is bit 0, pin M is bit 1, pin N is bit 2, pin P is bit 3, and pin R is bit 4. Therefore, to select task #21 you would have to assert pins L, N and R.</p> <p>The size of this input function is 1 bit, except on fieldbus where it can be any size to fit the need.</p> <p>Configuration:</p> <p> Contact Type:</p> <p> Normally Open (N.O.)</p> <p> Normally Closed (N.C.)</p> <p> Bit: Type in the number you wish this bit to be in your binary number scheme to select tasks.</p> <p> Mode: All TASK SELECT BITs must be the same mode, no mixing of modes allowed.</p> <p> Binary – Will create a decimal number equivalent to the weighted value of this binary bit(s).</p> <p> Binary + 1 – Will create a number equivalent to the weighted value of this binary bit(s) and add the value of one (1) to that number.</p>	Bit Number	4	3	2	1	0	Weighted Value	16	8	4	2	1	Binary Number	1	0	1	0	1	24 VDC Pins (example)	R	P	N	M	L
Bit Number	4	3	2	1	0																				
Weighted Value	16	8	4	2	1																				
Binary Number	1	0	1	0	1																				
24 VDC Pins (example)	R	P	N	M	L																				
JOB SELECT BIT	<p>When asserted or removed, on any input type, the controller will select a job. This is one bit of a binary number created by many of these bits.</p> <p>See TASK SELECT BIT function description for explanation of this bit, keeping in mind this is referenced to jobs not tasks.</p> <p>The size of this input function is 1 bit except on fieldbus where it can be any size to fit the need.</p> <p>Configuration:</p> <p> Contact Type:</p> <p> Normally Open (N.O.)</p> <p> Normally Closed (N.C.)</p> <p> Bit: Type in the number you wish this bit to be in your binary number scheme to select jobs.</p> <p> Mode: All JOB SELECT BITs must be the same mode, no mixing of modes allowed.</p> <p> Binary – Will create a decimal number equivalent to the weighted value of this binary bit(s).</p> <p> Binary + 1 – Will create a number equivalent to the weighted value of this binary bit(s) and add the value of one (1) to that number.</p>																								
REVERSE	<p>When asserted, on any input type, the controller will place the tool in Reverse (disassembly) mode. This will NOT run the tool in Reverse mode, it simply changes the tool mode from</p>																								

Alpha Controller

Inputs	Description
	Forward to Reverse. If one input to do both functions is desired, see the input function REVERSE
START	<p>When removed, from any input type, the controller will place the tool into Forward (assembly) mode.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p> Contact Type:</p> <p> Normally Open (N.O.)</p> <p> Normally Closed (N.C.)</p>
DISABLE TASK	<p>When asserted, on any input type, the controller will disable the tool while this specific task is selected. This will act like a STOP to stop the tool during use. Use the Task parameter under Configuration to select the task to be disabled when this input is asserted.</p> <p>When removed the tool will be allowed to run while this specific task is selected.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p> Contact Type:</p> <p> Normally Open (N.O.)</p> <p> Normally Closed (N.C.)</p> <p> Task: Type in the task number you wish to disable when this input is asserted.</p>
DISABLE JOB	<p>When asserted, on any input type, the controller will disable the tool while this specific job is selected. This will act like a STOP to stop the tool during use. Use the JOB parameter under Configuration to select the job to be disabled while this input is asserted.</p> <p>When removed the tool will be allowed to run while this specific job is selected.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p> Contact Type:</p> <p> Normally Open (N.O.)</p> <p> Normally Closed (N.C.)</p> <p> Job: Type in the job number you wish to select when this input is asserted.</p>
TASK VERIFY	<p>When asserted, on any input type, the controller will verify the active task number is equal to the task number selected by this input. Use the TASK parameter under Configuration to select the task number to verify. If the wrong task is selected the tool will be disabled.</p> <p>When removed verification will not happen.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p> Contact Type:</p> <p> Normally Open (N.O.)</p> <p> Normally Closed (N.C.)</p> <p> Task: Type in the task number you wish to verify when this input is asserted.</p>
JOB VERIFY	<p>When asserted, on any input type, the controller will verify the active job number is equal to the job number selected by this input. Use the JOB parameter under Configuration to select the job number to verify. If the wrong job is selected the tool will be disabled.</p> <p>When removed verification will not happen.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p> Contact Type:</p> <p> Normally Open (N.O.)</p> <p> Normally Closed (N.C.)</p> <p> Job: Type in the job number you wish to verify when this input is asserted.</p>
TASK VERIFY BIT	<p>When asserted, on any input type, the controller will verify the active task number is equal to the task number selected by this input. Use the BIT parameter under Configuration to select the task number to verify. If there is a mismatch between the active task and the</p>

Inputs	Description
	<p>selected task the tool will be disabled. This is one bit of a binary number created by many of these bits. See TASK SELECT BIT to understand how to use bits to create binary numbers.</p> <p>When removed verification will not happen.</p> <p>The size of this input function is 1 bit except on fieldbus where it can be size any size to fit the need.</p> <p>Configuration:</p> <p> Contact Type: Normally Open (N.O.) Normally Closed (N.C.)</p> <p> Bit: Type in the number you wish this bit to be in your binary number scheme to verify a task.</p> <p> Mode: All TASK VERIFY BITs must be the same mode, no mixing of modes allowed.</p> <p> Binary – Will create a decimal number equivalent to the weighted value of this binary bit(s). Binary + 1 – Will create a number equivalent to the weighted value of this binary bit(s) and add the value of one (1) to that number.</p>
JOB VERIFY BIT	<p>When asserted, on any input type, the controller will verify the active job number is equal to the job number selected by this input. Use the BIT parameter under Configuration to select the job number to verify. If there is a mismatch between the active job and the selected job the tool will be disabled. This is one bit of a binary number created by many of these bits. See TASK SELECT BIT to understand how to use bits to create binary numbers.</p> <p>When removed verification will not happen.</p> <p>The size of this input function is 1 bit except on fieldbus where it can be any size to fit the need.</p> <p>Configuration:</p> <p> Contact Type: Normally Open (N.O.) Normally Closed (N.C.)</p> <p> Bit: Type in the number you wish this bit to be in your binary number scheme to verify a job.</p> <p> Mode: All JOB VERIFY BITs must be the same mode, no mixing of modes allowed.</p> <p> Binary – Will create a decimal number equivalent to the weighted value of this binary bit(s). Binary + 1 – Will create a number equivalent to the weighted value of this binary bit(s) and add the value of one (1) to that number.</p>
RESET RESULT STATUS	<p>When asserted, on any input type, the controller will reset to 0 (zero) any rundown results status output bits on the same type of I/O. Meaning, if this were asserted on DeviceNet, only the DeviceNet output status bits will be reset. Output status bits on other types of I/O will remain in their original state.</p> <p>The list of status bits that will reset are: CYCLE OK CYCLE NOK TORQUE OK TORQUE HIGH TORQUE LOW ANGLE OK ANGLE HIGH ANGLE LOW CYCLE ABORTED CYCLE STOP</p> <p>When removed nothing will happen.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p> Contact Type: Normally Open (N.O.)</p>

Alpha Controller

Inputs	Description
	Normally Closed (N.C.)
REVERSE START	<p>When asserted, on any input type, the controller will switch the tool mode to Reverse (Disassembly) AND start the tool. This is different from the REVERSE input function in that the REVERSE input function puts the tool into Reverse mode only.</p> <p>When removed the tool will stop and switch back to Forward mode.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p> Contact Type:</p> <p> Normally Open (N.O.)</p> <p> Normally Closed (N.C.)</p>
DISABLE TOOL	<p>When asserted, on any input type, the controller will prevent the tool from running. It does NOT stop the tool if the tool is running, but will prevent it from running when the next START signal is applied. The START input can come from any type of I/O or the tool trigger.</p> <p>When removed the tool is allowed to run after the next START input.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p> Contact Type:</p> <p> Normally Open (N.O.)</p> <p> Normally Closed (N.C.)</p>
*PART ID TRIGGER	<p>When asserted, on any fieldbus input type, the controller will read the new PART ID input and place the data into the Part ID buffer. This data is added to the rundown data and stored in the controller or sent out via the serial port or Ethernet. This input function is NOT available on the 24 VDC type of I/O. Also, the PART ID CHANGED output will go high. This lets the PLC programmer know the controller has read the new PART ID. See PART ID input function for explanation of handshake between controller and external PLC.</p> <p>When removed the PART ID CHANGED output goes low.</p> <p>The size of this input function is 1 bit.</p> <p>Configuration:</p> <p> Contact Type:</p> <p> Normally Open (N.O.)</p> <p> Normally Closed (N.C.)</p>
*PART ID	<p>When asserted, on any fieldbus input type, the controller will read the new PART ID input and place the data into the Part ID buffer. This data is added to the rundown data and stored in the controller or sent out via the serial port or Ethernet. This input function is NOT available on the 24 VDC type of I/O.</p> <p>The size of this input function can be any size from 0 to 32 bytes.</p> <p>When removed nothing will happen.</p> <p>Configuration:</p> <p>Length: Type in the length of the expected data string in bits.</p> <p>Trigger:</p> <p> Manual: A handshake must be performed in order for the controller to read the new PART ID. The definition of a handshake is as follows:</p> <ol style="list-style-type: none"> 1. The external PLC verifies the PART ID CHANGED output is low (0). 2. The external PLC writes the data into the PART ID fieldbus input. 3. The PLC sets the PART ID TRIGGER input high (1) to indicate the new PART ID data has been written and is ready for the controller to read it. 4. The controller will read the PART ID data into its memory and set the PART ID CHANGED output high (1) to indicate the data has been read. 5. The PLC reads the high level on the PART ID CHANGED output then sets the PART ID TRIGGER input to low (0). 6. The controller will set the PART ID CHANGED output to low (0). <p> Auto: The controller will read the PART ID when it changes automatically, no</p>

Inputs	Description
	handshake required.

4.2.2 Output Descriptions

Outputs	Description
OFF	
IN CYCLE	
JOB SELECTED	
DISASSEMBLY DETECTED	
TOOL RUNNING	
CYCLE OK	
CYCLE NOK	
TASK SELECTED	
JOB COMPLETE	
TASK COMPLETE	
TASK SELECTED BIT	
JOB SELECTED BIT	
TORQUE OK	
TORQUE HIGH	
TORQUE LOW	
ANGLE OK	
ANGLE HIGH	
ANGLE LOW	
CYCLE ABORTED	
STOPPED	
FAULTED	
READY	
PM	
*TORQUE	

Alpha Controller

Outputs	Description
*ANGLE	
*FAULT CODE	
*PARAMETER	
START TRIGGER	
MFB	
SNUG ACHIEVED	
CYCLE STOP	
*PART ID CHANGED	
STEP BIT	

Software Map

5.1 Setup

5.1.1 Wizard

- Strategy (Torque, Angle, Torque & Angle)
- Units (NM, FTLB, INLB, INOZ, KGM, NCM, NDM)
- Thread Direction (CW CCW)
- High Torque
- Low Torque
- Snug Torque
- High Angle
- Low Angle
- Speed
- Wobble (Angle Target, Speed, Max Torque)
- Slow Seek (Angle Target, Speed, Max Torque)
- Start Delay (Delay Time, Max Torque)
- Conditioner Fastener (Down Target Torque, Delay Time, Max Time, Up Angle Target)
- Pre-Torque (Torque Target, Delay Between Steps)
- ATC
- Backoff Fastener (Angle Target, Torque Target, Speed)
- Fastener Release (Speed, Angle Target, Max Torque)

5.1.2 Job

- Name
- Barcode ID
- Auto Sequence Tasks (Yes, No)
- Auto Reset Job (Yes, No)
- Enable Error Proofing

5.1.2.1 Task

- Name
- Batch Count
- Units (NM, FTLB, INLB, INOZ, KGM, NCM, NDM)
- Thread Direction (CW, CCW)
- Threshold Torque
- Statistical Threshold
- Disassembly Speed
- Disassembly Acceleration
- Cycle Lock-Out
- Torque Audit Step (Last, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12)
- Angle Audit Step (Last, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12)
- Torque Rate

- Torque Average
- Angle Interval
- Modified

5.1.2.2 Step

- Name
- Strategy TC/AM
 - Torque Target
 - High Torque
 - Low Torque
 - Snug Torque
 - High Angle
 - Low Angle
 - Angle Bailout
 - Downshift Mode (Disabled, Manual, ATC)
 - Manual: Downshift Mode
 - Manual: Downshift Speed
 - ATC: Starting Torque %
 - ATC: Ending Torque %
 - ATC: Ending Speed %
 - Soft Stop (Yes, No)
 - Yes: Current Off Time
 - Yes: Current Hold Time
 - Yes: Current Ramp Time
 - Speed
 - Power
 - Acceleration
 - Abort Timer
 - Delay Between Steps
 - Accumulate Angle (Yes, No)
- Strategy AC/TM
 - Snug Torque
 - Angle Target
 - High Angle
 - Low Angle
 - High Torque
 - Low Torque
 - Torque Bailout
 - Downshift Mode (Disabled, Manual)
 - Manual: Downshift Mode
 - Manual: Downshift Speed
 - Soft Stop (Yes, No)
 - Yes: Current Off Time
 - Yes: Current Hold Time
 - Yes: Current Ramp Time

Alpha Controller

- Speed
- Power
- Acceleration
- Abort Timer
- Delay Between Steps
- Accumulate Angle (Yes, No)
- Strategy AC/TC
 - Torque Target
 - High Torque
 - Low Torque
 - Torque Bailout
 - Snug Torque
 - Angle Target
 - High Angle
 - Low Angle
 - Angle Bailout
 - Downshift Mode (Disabled, Manual, ATC)
 - Manual: Downshift Mode
 - Manual: Downshift Speed
 - ATC: Starting Torque %
 - ATC: Ending Torque %
 - ATC: Ending Speed %
 - Soft Stop (Yes, No)
 - Yes: Current Off Time
 - Yes: Current Hold Time
 - Yes: Current Ramp Time
 - Speed
 - Power
 - Acceleration
 - Abort Timer
 - Delay Between Steps
 - Accumulate Angle (Yes, No)
- Strategy BACK
 - Snug Torque
 - Angle Target
 - High Angle
 - Low Angle
 - Torque Target
 - High Torque
 - Low Torque
 - Torque Bailout
 - Downshift Mode (Disabled, Manual, ATC)
 - Manual: Downshift Mode
 - Manual: Downshift Speed

- ATC: Starting Torque %
 - ATC: Ending Torque %
 - ATC: Ending Speed %
- Soft Stop (Yes, No)
 - Yes: Current Off Time
 - Yes: Current Hold Time
 - Yes: Current Ramp Time
- Speed
- Power
- Acceleration
- Abort Timer
- Delay Between Steps
- Accumulate Angle (Yes, No)
- Strategy RATE
 - Torque Rate Target
 - High Torque
 - Low Torque
 - Torque Bailout
 - Snug Torque
 - High Angle
 - Low Angle
 - Angle Bailout
 - Downshift Mode (Disabled, Manual, ATC)
 - Manual: Downshift Mode
 - Manual: Downshift Speed
 - ATC: Starting Torque %
 - ATC: Ending Torque %
 - ATC: Ending Speed %
- Soft Stop (Yes, No)
 - Yes: Current Off Time
 - Yes: Current Hold Time
 - Yes: Current Ramp Time
- Speed
- Power
- Acceleration
- Abort Timer
- Delay Between Steps
- Accumulate Angle (Yes, No)
- Strategy YIELD
 - Yield Target
 - High Torque
 - Low Torque
 - Torque Bailout
 - Snug Torque

Alpha Controller

- High Angle
- Low Angle
- Angle Bailout
- Downshift Mode (Disabled, Manual, ATC)
 - Manual: Downshift Mode
 - Manual: Downshift Speed
 - ATC: Starting Torque %
 - ATC: Ending Torque %
 - ATC: Ending Speed %
- Soft Stop (Yes, No)
 - Yes: Current Off Time
 - Yes: Current Hold Time
 - Yes: Current Ramp Time
- Speed
- Power
- Acceleration
- Abort Timer
- Delay Between Steps
- Accumulate Angle (Yes, No)
- Strategy AC/TA
 - Snug Torque
 - Angle Target
 - High Angle
 - Low Angle
 - Torque Target
 - High Torque
 - Low Torque
 - Max Torque Bailout
 - Mind Torque Bailout
 - Downshift Mode (Disabled, Manual, ATC)
 - Manual: Downshift Mode
 - Manual: Downshift Speed
 - ATC: Starting Torque %
 - ATC: Ending Torque %
 - ATC: Ending Speed %
 - Soft Stop (Yes, No)
 - Yes: Current Off Time
 - Yes: Current Hold Time
 - Yes: Current Ramp Time
 - Speed
 - Power
 - Acceleration
 - Abort Timer
 - Delay Between Steps

- Accumulate Angle (Yes, No)

5.1.3 Communications

- Obtain IP From Network (No, Yes)
 - IP Address
 - Subnet Mask
 - Gateway
 - DNS
 - Physical
- Serial
 - Serial Port 1 (Barcode/Printer, Barcode, Printer, ETB)
 - Serial Port 2 (Barcode/Printer, Barcode, Printer, Toyota, PFCS, Open)
- PFCS
 - Server IP
 - Port
 - Time Out
- Open
 - Port
 - Cell
 - Buffer while off line
- Toolsnet
 - Server IP
 - Port
 - Cell
 - Station

5.1.4 Other

- General
 - Name
 - Keypad Mode (Disabled, Task Select, Job Select, Part ID)
 - Count Mode (Count Up, Count Down)
 - Stop/Abort within Limits (OK, NOK)
- Users
 - Add
 - Manage
 - 1. Add
 - 2. Delete
 - 3. Change Password
 - 4. Change Access
- Outputs
 - C (Off, In Cycle, Job Selected, Disassembly Detected, Tool Running, Cycle OK, Cycle NOK, Task Selected, Job Completed, Task Complete, Task Selected Bit, Job Selected Bit, Torque OK, Torque Hi, Torque Low, Angle OK, Angle Hi, Angle Low, Cycle Aborted, Stopped, Faulted, Ready, PM, Start Trigger, MFB, Snug Achieved, Cycle Stopped, Step Bit)
 - D (Off, In Cycle, Job Selected, Disassembly Detected, Tool Running, Cycle OK, Cycle NOK, Task Selected, Job Completed, Task Complete, Task Selected Bit, Job Selected Bit,

Alpha Controller

- Torque OK, Torque Hi, Torque Low, Angle OK, Angle Hi, Angle Low, Cycle Aborted, Stopped, Faulted, Ready, PM, Start Trigger, MFB, Snug Achieved, Cycle Stopped, Step Bit)
- E (Off, In Cycle, Job Selected, Disassembly Detected, Tool Running, Cycle OK, Cycle NOK, Task Selected, Job Completed, Task Complete, Task Selected Bit, Job Selected Bit, Torque OK, Torque Hi, Torque Low, Angle OK, Angle Hi, Angle Low, Cycle Aborted, Stopped, Faulted, Ready, PM, Start Trigger, MFB, Snug Achieved, Cycle Stopped, Step Bit)
- F (Off, In Cycle, Job Selected, Disassembly Detected, Tool Running, Cycle OK, Cycle NOK, Task Selected, Job Completed, Task Complete, Task Selected Bit, Job Selected Bit, Torque OK, Torque Hi, Torque Low, Angle OK, Angle Hi, Angle Low, Cycle Aborted, Stopped, Faulted, Ready, PM, Start Trigger, MFB, Snug Achieved, Cycle Stopped, Step Bit)
- G (Off, In Cycle, Job Selected, Disassembly Detected, Tool Running, Cycle OK, Cycle NOK, Task Selected, Job Completed, Task Complete, Task Selected Bit, Job Selected Bit, Torque OK, Torque Hi, Torque Low, Angle OK, Angle Hi, Angle Low, Cycle Aborted, Stopped, Faulted, Ready, PM, Start Trigger, MFB, Snug Achieved, Cycle Stopped, Step Bit)
- H (Off, In Cycle, Job Selected, Disassembly Detected, Tool Running, Cycle OK, Cycle NOK, Task Selected, Job Completed, Task Complete, Task Selected Bit, Job Selected Bit, Torque OK, Torque Hi, Torque Low, Angle OK, Angle Hi, Angle Low, Cycle Aborted, Stopped, Faulted, Ready, PM, Start Trigger, MFB, Snug Achieved, Cycle Stopped, Step Bit)
- J (Off, In Cycle, Job Selected, Disassembly Detected, Tool Running, Cycle OK, Cycle NOK, Task Selected, Job Completed, Task Complete, Task Selected Bit, Job Selected Bit, Torque OK, Torque Hi, Torque Low, Angle OK, Angle Hi, Angle Low, Cycle Aborted, Stopped, Faulted, Ready, PM, Start Trigger, MFB, Snug Achieved, Cycle Stopped, Step Bit)
- K (Off, In Cycle, Job Selected, Disassembly Detected, Tool Running, Cycle OK, Cycle NOK, Task Selected, Job Completed, Task Complete, Task Selected Bit, Job Selected Bit, Torque OK, Torque Hi, Torque Low, Angle OK, Angle Hi, Angle Low, Cycle Aborted, Stopped, Faulted, Ready, PM, Start Trigger, MFB, Snug Achieved, Cycle Stopped, Step Bit)
- Inputs
 - L (Ignore, Start, Select Job, Select Task, Stop, Reset Job, Task Select Bit, Job Select bit, Reverse, Disable Task, Disable Job, Task Verify, Job Verify, Task Verify Bit, Job Verify Bit, Reset Result Status, Reverse Start, Disable Tool)
 - M (Ignore, Start, Select Job, Select Task, Stop, Reset Job, Task Select Bit, Job Select bit, Reverse, Disable Task, Disable Job, Task Verify, Job Verify, Task Verify Bit, Job Verify Bit, Reset Result Status, Reverse Start, Disable Tool)
 - N (Ignore, Start, Select Job, Select Task, Stop, Reset Job, Task Select Bit, Job Select bit, Reverse, Disable Task, Disable Job, Task Verify, Job Verify, Task Verify Bit, Job Verify Bit, Reset Result Status, Reverse Start, Disable Tool)
 - P (Ignore, Start, Select Job, Select Task, Stop, Reset Job, Task Select Bit, Job Select bit, Reverse, Disable Task, Disable Job, Task Verify, Job Verify, Task Verify Bit, Job Verify Bit, Reset Result Status, Reverse Start, Disable Tool)
 - R (Ignore, Start, Select Job, Select Task, Stop, Reset Job, Task Select Bit, Job Select bit, Reverse, Disable Task, Disable Job, Task Verify, Job Verify, Task Verify Bit, Job Verify Bit, Reset Result Status, Reverse Start, Disable Tool)
 - S (Ignore, Start, Select Job, Select Task, Stop, Reset Job, Task Select Bit, Job Select bit, Reverse, Disable Task, Disable Job, Task Verify, Job Verify, Task Verify Bit, Job Verify Bit, Reset Result Status, Reverse Start, Disable Tool)

- T (Ignore, Start, Select Job, Select Task, Stop, Reset Job, Task Select Bit, Job Select bit, Reverse, Disable Task, Disable Job, Task Verify, Job Verify, Task Verify Bit, Job Verify Bit, Reset Result Status, Reverse Start, Disable Tool)
- U (Ignore, Start, Select Job, Select Task, Stop, Reset Job, Task Select Bit, Job Select bit, Reverse, Disable Task, Disable Job, Task Verify, Job Verify, Task Verify Bit, Job Verify Bit, Reset Result Status, Reverse Start, Disable Tool)
- Triggers
 - Tap Action (Disabled, Reverse, Task Select, Arm, Reset Reject, Job Select, Job Reset)
 - Hold Action (Disabled, Reverse, Task Select, Arm, Reset Reject, Job Select, Job Reset)
 - Start Input (Any, All, Lever, PTS, None)
- Lights
 - Lights (1,2) (Task, Job)
 - Headlight Timer
- Tones
 - Accept Tone (None, Beep, Beeeep, Tocatta, Fifth, Turkishmarch, Funeralmarch, Ninth, Michigan, Ohio)
 - Reject Tone (None, Beep, Beeeep, Tocatta, Fifth, Turkishmarch, Funeralmarch, Ninth, Michigan, Ohio)
- Tool
 - PM Limit
 - Temperature Limit
 - Torsion Factor
 - Requires Arming (No, Yes)
- Stats
 - Population
 - Subgroup Size
- Clock
 - Time
 - Date

5.1.5 Full Backup/Restore

- Backup
- Restore
- Defaults

5.2 Service

5.2.1 Tool

- About
 - Model
 - Serial
 - Software Version
 - Max Torque
 - Max Speed
- Counters
 - Odometer
 - PM Counter
 - Trip Counter

Alpha Controller

- Cal
 - Nominal Cal
 - Torque Cal
 - Modified

5.2.2 Controller

- About
 - Model
 - Serial
 - Software Version
 - Servo Version
- Update

5.3 Analyze

- Results
- Cap
- Perform
- Cam
- Export
 - 1. Rundown Data (save)
 - 2. Fault Event Data (save)
- Job1.1 (Job, Task)
- 1. Rundown Data

Appendix A – Embedded Toolbox

Glossary

Abort Timer	The tightening cycle aborts if the tool does not shutoff before this pre-selected time.
Acceleration	How fast the controller changes the speed of the tool from 0 (stopped) to the rated speed.
Accept Tone	Controls the tone made from the handle of handheld QPM tools for accepted tightening cycles. Allows distinct tones for tools in adjacent workstations.
AC/TA	Angle Control Torque Averaging.
AC/TC	Angle Control Torque Control. This strategy controls a tool based on angle and Torque.
AC/TM	Angle Control with Torque Monitor. This strategy controls a tool based on angle and monitors the torque limits defined by user.
Angle Interval	(Rate, Yield and AC/TA) Angle interval is used to calculate Torque vs. Angle Rate. A larger interval tends to give a smoother rate.
ATC	Allows Adaptive Tightening Control modes to be selected, so that consistent torque can be maintained over a wide range of joints. Manual downshift should be used when: <ul style="list-style-type: none"> • High Prevailing Torques – Prevailing Torque > 20% of the Torque Set Point (TSP). • High Starting Torque – Starting Torque > 20% of TSP.
Auto Sequence Tasks	Enables the tool setup for the next task after the batch count is achieved for the prior task in a Job.
BACK	Back-Off. This strategy functions after Angle Control with Torque Monitor (AC/TM). It loosens the fastener (turns it the opposite direction from tightening).
Batch Count	The number of tightening cycles required to be within specified limits to complete a batch. The Run display shows the batch count and number of complete tightening cycles. Defines the number of rundowns required to be completed for each task.
Downshift Mode	Disable: no downshift; Manual: Occurs at specified torque; ATC automatically adapts to the joint.
Downshift Speed	Once the tool reaches the Downshift Torque point, the controller changes the operating speed of the tool from the initial Tool Speed to the Downshift Speed.
Downshift Torque	The controller changes the operating speed of the tool from the initial Tool Speed to the Downshift Speed at the Downshift Torque level.
High Angle	Anytime the peak angle recorded exceeds the High Angle, the tightening cycle is recorded as a reject for high angle, the high angle light (red) illuminates and the tightening cycle is given an overall status of NOK.
High Torque	Anytime the peak torque recorded exceeds the High Torque, the tightening cycle is recorded as a reject for high torque, the high torque light (red) illuminates and the tightening cycle is given an overall status of NOK.
Jobs	Define one or more assembly sequences that can include multiple fasteners controlled by one or more tasks.
Low Angle	Anytime the peak angle recorded during the Angle Audit Step fails to reach the Low Angle, the tightening cycle is recorded as a reject for low angle, the low angle light (yellow) illuminates and the tightening cycle is given an overall status of NOK.
Low Torque	When the peak torque recorded fails to reach the Low Torque, the tightening cycle is recorded as a reject for low torque, the low torque light (yellow) illuminates and the tightening cycle is given an overall status of NOK.
MFP Mode	Controls the operation of the multiple-function panel (MFP) on QPM tools. Choices includes: MFB Tap (Disabled, Reverse, Task Sel, Arm, Rst Rej, Job Sel, Job Rst) and MFB Hold (Disabled, Reverse, Task Sel, Arm, Rst Rej, Job Sel, Job

	Rst). The default value is Disabled.
Odometer	The odometer increments after every in cycle to tracks the total tool cycles. It cannot be reset.
Parameter Set	Now referenced as a Task.
PM Counter	Records the number of tightening cycles completed since the last time it was reset for Planned Maintenance.
PM Counter	The PM (preventative maintenance) counter tracks the total tool cycles until maintenance is required.
PM Limit	When the PM Counter exceeds the PM Limit, the controller provides a maintenance alert.
RATE	RCAM Torque Rate Control. This strategy uses an increase in Torque Rate Control to a specified level to indicate a fastening process event.
Reject Tone	Controls the tone made from the handle of handheld QPM tools for rejected tightening cycles. Allows distinct tones for tools in adjacent workstations.
Slow Seek	Slow Seek helps engage the socket or fastener at a pre-selected speed, torque level and angular rotation. Once engaged, the tightening cycle completes at a higher speed. Slow Seek prevents cross threaded fasteners and previously secured fasteners from being counted in a batch.
Snug Torque	The controller begins to monitor the tool for angle at a pre-selected threshold torque. Any increase in angle after the snug point results in a corresponding increase in the tension or clamp load within the joint.
Soft Stop	Soft stop minimizes the torque impulse to the operator during tool shutoff at the end of the tightening cycle.
Speed	The speed at which the tool operates during the initial portion of the tightening cycle prior to ATC or downshift.
Spindle	A spindle represents a connection to a hand held or fixtured tool connected to a controller.
Steps	Instructions to operate a tool defined by available strategies such as TC/AM (Torque Control, Angle Monitoring).
Strategy	Identifies what variables will be used to control the tool during a tightening cycle.
System Outputs	(Tool Running, In Cycle, Cycle OK, Cycle NOK, Disassembly Detected, Indicate Job) also fixed and pulsed
Task	Control tool operation for tightening a fastener which can have one or more steps. A collection of instructions that define how the tool should perform the tightening process. It may be selected from the keypad or 24V device such as a socket tray. Formerly referenced as Parameter Set.
TC/AM	Torque Control with Angle Monitoring. This strategy controls a tool based on torque and monitors the angle limits defined by user.
Thread Direction	Sets assembly direction to clockwise (CW) or counter clockwise (CCW).
Threshold Torque	Sets the point at which the tool is "In Cycle." When the tool is "In Cycle" the tool and controller tightening cycle status lights turn off, the controller displays dashes (-) for data, and the "In Cycle" output is turned on.
Tool Tones	Distinctive sounds assigned to tool functions.
Torque Average	(Rate, Yield and AC/TA) Number of torque samples averaged for rate calculation. Torque samples are taken every millisecond. A running average is calculated based on these samples. A higher number gives a smoother rate.
Torque Calibration	Determines how torque values are assigned to the electrical signals from the torque transducer on the tool. This value is unique to each tool and changes over time.
Torque Target	When the tool is being controlled for torque, the torque target instructs the controller when to shutoff the tool. The torque target should be greater than Low Torque and less than High Torque, and is required for torque control.
Trace	A display plot of torque versus time (or angle) of a tightening cycle.
Trip Counter	Records the number of total tool tightening cycles completed since the last time it was reset. It is usually used as a supplementary count of the PM Counter.

Alpha Controller

Units	The following torque units and associated labels are used with Stanley controllers and tools.			
	Abbreviation	Common Term	= 1 lbfft	= 1 Nm
	Nm	Newton meter	1.355 818	1
	Ncm	Newton centimeter	135.581 8	100
	Ndm	Newton decimeter	13.5582	10
	kgm	Kilogram meter	0.138 255 2	0.101 971 6
	kgcm	Kilogram centimeter	13.825 52	10.197 16
	ftlb	Foot pound	1	0.737 562 1
	inlb	Inch pound	12	8.850 745
	inoz	inch ounce	192	141.611 9
YIELD	YCAM Yield Control. This strategy uses Torque vs. Angel Rates as the control variable.			

Warranty

Warranty

Mechanical Products Limited Warranty:

STANLEY ASSEMBLY TECHNOLOGIES (“Stanley”) warrants its Assembly Technologies mechanical products to the original purchaser to be free from deficiencies in material or workmanship for the useful life of the product.

Under this lifetime limited warranty Stanley will, at its discretion, repair or replace any product which, upon inspection, is acknowledged by Stanley to be defective.

This limited lifetime warranty shall apply to products which have been used under normal operating conditions for their intended use and shall not apply to products which have been subjected to: abnormal wear and tear, abuse, misuse, improper maintenance, negligence, continued use after partial failure, accident, alterations or repairs with non-genuine Stanley replacement parts.

Electronic Products Limited Warranty:

Stanley warrants its Assembly Technologies electronic products to the original purchaser to be free from deficiencies in material or workmanship for a period of one year after the date of shipment.

Under this limited warranty Stanley will, at its discretion, repair or replace any product which, upon inspection, is acknowledged by Stanley to be defective.

This warranty shall apply to products which have been used under normal operating conditions for their intended use and shall not apply to products which have been subjected to: abnormal wear and tear, neglect, component degradation, improper handling, overload, abuse, misuse, improper maintenance, use with improper accessories, or where alterations have been made.

Software Products Limited Warranty:

Stanley warrants its Assembly Technologies software products to the original purchaser to be free from deficiencies in material or workmanship for a period of one year after the date of shipment.

Under this limited warranty Stanley will, at its discretion, make available replacement software or an upgrade for any product which, upon inspection, is acknowledged by Stanley to be defective. Installation of the software shall be the responsibility of the requestor.

This warranty shall apply to products which have been used with specified, compatible hardware under normal operating conditions for their intended use and shall not apply to products which have been: modified, misused, improperly handled, improperly maintained, or used with non-compatible hardware or accessories.

OEM Products Limited Warranty:

Some Stanley Assembly Technologies custom engineered systems include components manufactured by others. The limited warranties of each individual manufacturer shall apply to these components and Stanley makes no representation or warranty of any kind, expressed or implied, with respect to such components.

General Terms:

This limited warranty gives you specific legal rights and is in lieu of all other warranties, expressed or implied, including the implied warranties of merchantability and fitness for a particular purpose. Some states and countries do not allow limitations on implied warranties, so the above may not apply to you. You may also have other rights which vary by state or country.

Stanley shall not be responsible for incidental or consequential damages or the inability to use its products for any purpose whatsoever. Stanley's maximum liability shall not in any case exceed the

contract price for the products claimed to be defective. Some states and countries do not allow the exclusion or limitation of incidental or consequential damages, so this specific limitation or exclusion may not apply to you.

Specification Changes:

Stanley retains the right to discontinue and/or change specifications of any Assembly Technologies products without responsibility for incorporating changes in products already sold.

Warranty Claims:

To apply for warranty consideration, the original purchaser should take the following action:

Contact the Stanley Assembly Technologies customer service department to obtain a "Return Authorization Number" and "Warranty Claim Report Form."

Package the product including proof of purchase and the completed warranty claim form.

Note the Return Authorization Number on the exterior of the package and return freight to:

*Stanley Assembly Technologies
5335 Avion Park Drive
Cleveland, Ohio 44143-2328*

In the event that a product is repaired or replaced under the terms of the warranty, the warranty period of the repaired or replacement product shall be limited to the remaining portion of the original warranty period.

Product Services

Stanley provides full services for design, modification, service, repair, and training on Stanley products.

Contact **STANLEY ASSEMBLY TECHNOLOGIES** or their agents for information on training courses to aid users in becoming familiar with operations, maintenance, or programming of the Stanley DC electric tools and controllers.

No modification of Stanley tools and controllers can be made without the express permission of **STANLEY ASSEMBLY TECHNOLOGIES**. Refer all service to **STANLEY ASSEMBLY TECHNOLOGIES**, or their representatives.

Return Material Authorization (RMA) Procedures

A Return Material Authorization or RMA is required before returning any material for warranty or repair service.

- Contact **STANLEY ASSEMBLY TECHNOLOGIES** or their agents.
- Request Customer Service or Repair Services.



NOTE:

An RMA can be given without a purchase order. However, non-warranty repairs cannot be performed until a written purchase order or credit card authorization is received.

- Have the following information available for the person answering the telephone to obtain an RMA:
 - Company name and address.
 - A contact name and telephone number. If possible, have facsimile and pager numbers (if any) available.
 - The Stanley model number, serial number, and description for the item
 - A short description of the problem.

Alpha Controller

Contacts

STANLEY ASSEMBLY TECHNOLOGIES: 5335 Avion Park Drive, Cleveland, Ohio 44143-2328 USA Tel: +1 (440) 461-5500 Fax: +1 (440) 461-5592; SATinfo@stanleyworks.com

STANLEY ASSEMBLY TECHNOLOGIES: 1875 Research Drive, Suite 200 Troy, Michigan 48092 USA Tel: +1 (248) 824-1100 Fax: (248) 824-1110 Toll Free Service: (877) 787-7830 Toll Free Sales: (877) 709-8006

STANLEY WORKS Ltd. (FRANCE): Outils Portatifs et Systemes d'Assemblage, Zone Imoparc bat Loire 4, 78190 Trappes, France Tel: +33 (1) 3050 9100 Fax: +33 (1) 3051 0708

STANLEY GERMANY, Inc.: Frankfurter Strasse 74, D-64521 Gross-Gerau, Germany Tel: +49 (0) 6152 8052-0 Fax: +49 (0) 6152 8052-22 SATGER@stanleyworks.com

STANLEY TOOLS S.r.l. (ITALY): Divisione Assembly Technologies, 47 Via Parco, 20046 Biassono (MI) Tel: +39 (039) 2389.1 Fax: +39 (039) 2389970

STANLEY ASSEMBLY TECHNOLOGIES: Gowerton Road, Brackmills, Northhampton NN4 7BW, England Tel: +44 (1604) 827247 Fax: +44 (1604) 827277

STANLEY ASSEMBLY TECHNOLOGIES SHANGHAI REPRESENTATIVE OFFICE: Room 1908, Shanghaimart Tower, 2299 Yan An Road West, Shanghai 200336, China Tel: 011-86-21-3208-4550 Fax: 011-86-21-6236-0191

www.StanleyAssembly.com